

5 GHz RF Modem User Manual

Document Number 4050-9901
Rev Number 05
Date 31-Jan-2007



10 Bearfoot Road, Northborough, MA 01532
Tel: (508) 393-3700 Fax: (508) 393-3157
Internet: www.protiumtechnologies.com

RESTRICTIONS ON USE, DUPLICATION OR DISCLOSURE OF PROPRIETARY INFORMATION

This document contains information proprietary to Protium Technologies, Inc. No part of this publication may be copied, distributed, transmitted, stored in a retrieval system or translated into any human or computer language without prior written permission of Protium Technologies, Inc.

Copyright © 2005, 2006, 2007 Protium Technologies, Inc.

Revision History

Rev	Date	Author	Comments
01	16-Aug-2005	M. Smutek / R. Hughes	Preliminary version
02	14-Nov-2005	M. Smutek	Revisions & additional commands
03	17-Jan-2006	M. Smutek / R. Hughes	Additional commands and updates, MIB, licenses, warranty, installation & configuration
04	07-Feb-06	M. Smutek / R. Hughes	Glossary. RF radiation warning. Miscellaneous clarifications and editorial corrections.
05	30-Jan-07	M. Smutek / R. Hughes	Updates including addition of Model 4050R rack mount unit, data sharer, local management user accounts, SNMPv3, configuration defaults, and changes to local management commands.

FCC COMPLIANCE STATEMENT

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's expense.

WARNING RF EXPOSURE HAZARD

Under certain operational circumstances and when connected to a typical high gain directional antenna, this equipment is capable of producing RF radiation exposure in excess of the limits defined in FCC 47CFR 1.1310, Table 1. Personnel working in the vicinity of an energized antenna should ensure that they maintain a distance of at least 4.2 feet (1.28 meters) from the antenna in the direction of maximum gain. All antenna maintenance activities should be performed only when the associated RF Modem transmit power has been muted.

NOTICE

Protium Technologies, Inc. has made every effort to ensure that the instructions contained in this document are adequate and free of errors or omissions. Protium Technologies, Inc. will, if necessary, explain issues that may not be covered by this document. Protium Technologies, Inc.'s liability for any errors in this document is limited to the correction of errors and the aforementioned advisory services.

This document has been prepared for professional and properly trained personnel and the customer assumes all responsibility when using this document. Protium Technologies, Inc. welcomes customer comments as part of the process of continual development and improvement of the documentation. Please submit your comments to Protium Technologies, Inc. at the following address:

Protium Technologies, Inc.
10 Bearfoot Road
Northborough, MA 01532
Phone: 508-393-3700
Facsimile: 508-393-3157

To allow for the introduction of design improvements, specifications are subject to change without notice.

Table of Contents

1	Introduction.....	8
1.1	System Overview	8
1.2	Features	8
2	Installation and Configuration	9
2.1	General Installation and Operating Considerations	9
2.1.1	Antenna	9
2.1.2	Site Planning.....	9
2.1.3	Cooling.....	9
2.1.4	Shielding and Grounding.....	9
2.2	Configuration Procedure	10
2.2.1	Account & Password Setup.....	10
2.2.2	Radio Configuration	10
2.2.3	Data Channel Configuration	11
2.2.4	Remote Management Port Configuration.....	14
2.3	Factory Configuration	17
3	Monitoring Operation	18
3.1	Activity Indicators.....	18
3.1.1	Transmit Activity Indicator.....	18
3.1.2	Receive Activity Indicator.....	18
3.1.3	Data Error Indicator.....	18
3.2	Alarms	18
3.2.1	System Alarms.....	19
3.2.2	Data Alarms.....	19
3.2.3	Transmit Alarms.....	19
3.2.4	Receive Alarms.....	19
3.3	Status	19
4	Local Craft Interface.....	21
4.1	Craft Interface Terminal Port	21
4.2	Commands.....	21
4.2.1	accounts Login Accounts	21
4.2.2	agc Automatic Gain Control.....	21
4.2.3	agcstatus Status.....	21
4.2.4	alarms Display Alarms	22
4.2.5	apc Automatic Power Control	22
4.2.6	channel Select Data Channel.....	22
4.2.7	clear Clear Screen	22
4.2.8	clock Clock Mode.....	22
4.2.9	config Configuration.....	23
4.2.10	dash Dash Variation	23
4.2.11	delaccount Delete Login Account	23
4.2.12	dhcp DHCP Enable.....	23
4.2.13	dhcpinfo DHCP Information.....	24

4.2.14	<i>dns Domain Name Server</i>	24
4.2.15	<i>gateway Network Gateway</i>	24
4.2.16	<i>help / ? Help</i>	25
4.2.17	<i>hostname Hostname</i>	25
4.2.18	<i>ident Identify</i>	25
4.2.19	<i>ifinfo Ethernet Interface Information</i>	25
4.2.20	<i>interface Interface Driver</i>	25
4.2.21	<i>interleave Interleave Data Blocks</i>	26
4.2.22	<i>ip Internet Protocol Address</i>	26
4.2.23	<i>linestat Display Serial Line Status</i>	26
4.2.24	<i>loghost Loghost Address</i>	26
4.2.25	<i>loop Loopback Mode</i>	27
4.2.26	<i>mac Media Access Control (MAC) Address</i>	27
4.2.27	<i>mod Modulation</i>	27
4.2.28	<i>multipoint Multipoint Handshaking</i>	28
4.2.29	<i>mute Mute the RF output</i>	28
4.2.30	<i>netconfig Network Configuration Summary</i>	28
4.2.31	<i>netflash Update Software via the Network</i>	28
4.2.32	<i>netmask Network Mask</i>	29
4.2.33	<i>newaccount Create Login Account</i>	30
4.2.34	<i>passwd Set Passwords</i>	30
4.2.35	<i>rsl Received Signal Level</i>	30
4.2.36	<i>rslthr RSL Alarm Threshold</i>	30
4.2.37	<i>rtsenable Data Sharer RTS Enable or Disable</i>	30
4.2.38	<i>rxfreq Receive Frequency</i>	31
4.2.39	<i>sharer Data Sharer Available</i>	31
4.2.40	<i>sharerout Data Sharer Output Selection</i>	31
4.2.41	<i>speed Set Interface Speed</i>	32
4.2.42	<i>stats Error Correction Statistics</i>	32
4.2.43	<i>syslog System Logging</i>	33
4.2.44	<i>temp Temperature</i>	33
4.2.45	<i>tempthr Temperature Alarm Thresholds</i>	33
4.2.46	<i>testmode Test LEDs, Fans, Relays</i>	34
4.2.47	<i>timeserver Time Server</i>	34
4.2.48	<i>txfreq Transmit Frequency</i>	34
4.2.49	<i>txpower Transmit Power Level</i>	35
4.2.50	<i>uptime System Uptime</i>	35
4.2.51	<i>version Version</i>	35
5	SNMP - Simple Network Management Protocol	36
5.1	Overview	36
5.2	MIBs	36
5.3	SNMP Tools	36
5.4	Account Management	36
5.4.1	Creating a User.....	37
5.4.2	Changing a User's Pass Phrases.....	39

5.4.3	<i>Deleting a User</i>	39
6	Specifications	40
7	Connectors	42
7.1	Front & Rear Panels	42
7.1.1	<i>Remote Unit</i>	42
7.1.2	<i>Rack-mount Unit</i>	43
7.2	Pin-out Tables	44
7.2.1	<i>Data Port</i>	44
7.2.2	<i>Craft Interface Terminal (CIT) Port</i>	45
7.2.3	<i>Alarm Relays</i>	45
7.2.4	<i>Ethernet</i>	46
7.2.5	<i>Power</i>	46
8	Software Licenses	47
8.1	Open Source Software.....	47
8.2	Protium Technologies, Inc. Software License	47
9	Warranty and Service Information	48
Appendix A Protium Technologies, Inc. MIBs		49
A.1	Protium Technologies, Inc. Enterprise MIB	49
A.2	Protium Technologies, Inc. Model 4050 MIB	50
Appendix B Software Licenses		65
B.1	Protium Technologies, Inc. Proprietary Software License	65
B.2	GNU General Public License, Version 2	67
B.3	GNU Library General Public License, Version 2	73
Appendix C GLOSSARY		82

1 Introduction

1.1 System Overview

The Models 4050 and 4050R are 5 GHz full-duplex Radio Frequency (RF) modems with link speeds of 64 and 128 Kbps. Data formats are synchronous serial, asynchronous serial, and 10Base-T Ethernet. The Model 4050R is intended for rack mount applications and includes a two port data sharing feature. The Model 4050 is typically used as an embedded modem or in standalone applications.

1.2 Features

Radio

- 5 GHz operation (5.091 – 5.101 and 5.140 – 5.150 GHz)
- Transmit power: 1W up to 50°C
- Occupied bandwidth: 100 KHz @ 64 Kbps, 200 KHz @ 128 Kbps
- Sensitivity: -98 dBm @ 64 Kbps, -96 dBm @ 128 Kbps
- Dynamic range: 70 dB
- Point-to-point
- Point-to-multipoint (TX keyed by RTS)

Modem

- Link speed: 64 or 128 Kbps (automatically set by data interface)
- Error correction: Reed-Solomon
- Interleave depth: 0 to 6

Data Interfaces

- Serial: synchronous or asynchronous (software selectable)
- Synchronous speeds: 64 or 128 Kbps
- Synchronous clock: internal, external, or looped (software selectable)
- Asynchronous speeds: 300 – 19200 bps
- Interface: EIA-232 and EIA-530 (software selectable)
- DB-25F connector (DCE)
- Two port data sharer (modem 4050R)
- Ethernet 10Base-T (layer 2, protocol independent)

Management

- Local serial port (9600, 8N1)
- DE-9F (DCE)
- Command line interface
- Password protected (three authorization levels)
- Alarm status LEDs (front and rear panels, four each)
- Alarm contact closures (solid-state, four form A)
- Ethernet 10Base-T management port
- DHCP capable
- SNMP V3

2 Installation and Configuration

2.1 General Installation and Operating Considerations

2.1.1 Antenna

Avoid operating the transmitter without a proper termination on the RF connector. Although the modem is designed to withstand such operation, undesired interference to other RF systems may occur.

A typical installation will require the use of a high gain antenna. Proper alignment of the antenna is critical to ensuring an error-free link. During the alignment process, an **rs1** command from the Craft Interface Terminal (CIT) will display near real-time receive signal strength and may be used to “peak” the antenna positioning.

This equipment produces RF radiation when connected to a typical high gain directional antenna. Personnel working in the vicinity of an energized antenna should ensure that they maintain a distance of at least 4.2 feet (1.28 meters) from the antenna in the direction of maximum gain. See the caution statement at the beginning of the manual.

The RF Modem is shipped with the transmitter set in the “mute” condition. This is done to prevent inadvertent transmission on an unauthorized frequency. All operating parameters, including an estimate of the minimum necessary transmit power, should be programmed into the modem before un-muting the transmitter.

Do not exceed +10 dBm input power at the antenna terminal of the RF Modem or damage to the unit may result.

2.1.2 Site Planning

As with any wireless link, proper system and path planning is essential to ensuring error-free operation. Such planning should take into consideration path clearances from obstructions, interference from nearby radiators, multi-path reflections and fading. A system signal strength margin of at least 20 dB above the rated receiver threshold is standard practice.

When installing multiple modems in the same general location, ensure that they are all transmitting within the same sub-band to prevent interference and desensitization.

2.1.3 Cooling

Install the RF Modem so that adequate airflow can be maintained through the rear and side or front vents. If airflow is restricted, the modem internal temperature may rise above the preset thermal shutdown temperature.

2.1.4 Shielding and Grounding

When the DB-25F connector is used for the RF Modem EIA-530/232 data I/O, ensure that a good quality shielded cable is used and that the cable shield is electrically terminated to the cable connector shells.

A grounding stud is provided on the rear panel. A ground braid should be attached to this lug and connected to a local earth ground to prevent static charge build-up on the modem, antenna and associated cabling.

2.2 Configuration Procedure

2.2.1 Account & Password Setup

Access to the local management port requires logging in with an account name and corresponding password. As shipped from the factory, there is a single account name of “admin”. Any other accounts required may be created after first logging in with the “admin” account.

There are two types of accounts: administrator and operator. An administrator account has access to all configuration settings and information displays while an operator account has some limitations on what is available to display and change. The type of account is specified when any new account is created.

Only administrators may create new accounts or delete existing accounts.

2.2.1.1 *Initial logon*

When the local management port is first accessed, enter “admin” as the account name and simply press ‘enter’ or ‘return’ when prompted for the password. There initially is no password and a new password must be set before proceeding. The system will automatically prompt for a new password and will not proceed until that is done successfully.

Note: once the password is set, there is no way to subsequently access the management functions without a password. Set the password carefully and do not forget it. It is impossible to recover from a lost password unless there is at least one administrative account available with a known password.

It is suggested that the ‘admin’ account never be used for day-to-day management of the system and instead be reserved for emergency access in the event other administrative passwords are lost.

2.2.1.2 *Account creation*

After logging in for the first time, it is suggested that additional accounts be created immediately and that the new accounts be used for normal day-to-day management.

A new account is created using the **newaccount** command and specifying an account name and account type. For example, the following command will create a new administrative account with the name “accountname”:

```
> newaccount accountname admin
```

See the description of the **newaccount** command for more details. Additional account management commands are **accounts** to list all accounts, **delaccount** for deleting accounts, and **passwd** for changing the password on an existing account.

You may wish to log off the “admin” account and use the new account for any additional configuration.

2.2.2 Radio Configuration

A configuration summary with all of the important configuration settings for the radio and the data interface may be displayed with the **config** command.

2.2.2.1 *Dash Setting*

The modems come in two configurations known as “dash one” and “dash two.” The “dash one” modems transmit at a lower frequency than they receive while the “dash two” modems are the reverse. One modem of each type is required to form a link.

IMPORTANT: The dash setting corresponds to a physical configuration internal to the modem and should not be changed.

2.2.2.2 Receive Frequency

The receive frequency should be set with the command:

```
> rxfreq ffff.f
```

The receive frequency of each modem must equal the transmit frequency of the other modem in the link. The frequency is specified in 0.1 MHz steps.

2.2.2.3 Transmit Frequency

The transmit frequency should be set with the command:

```
> txfreq ffff.f
```

The transmit frequency of each modem must equal the receive frequency of the other modem in the link. The frequency is specified in 0.1 MHz steps.

2.2.2.4 Transmit Power

The transmit power should be set with the command:

```
> txpower nn.n
```

The transmit power level is specified in dBm, adjustable in 0.5 dB steps.

2.2.2.5 RSL Threshold

The RF Modem has a programmable Receive Signal Level (RSL) threshold detector that may be used to evaluate link margin. When the receive signal level drops below the programmed threshold, the RX alarm will be set. This threshold is set at the factory to a default value of -110 dBm to minimize the chance of inadvertent RSL alarms during initial system setup. The user should set the RSL alarm threshold so that RSL alarm events are generated at an appropriate level depending on the actual operating conditions.

The RSL threshold should be set with the command:

```
> rsltr -nn.n
```

The threshold value is specified in dBm.

2.2.2.6 Mute

The modem is configured at the factory with mute on. Mute should not be turned off until the frequency and power settings are set correctly and an appropriate antenna (or load) is attached to the antenna connector.

2.2.3 Data Channel Configuration

2.2.3.1 Channel Selection

The modems may be configured to carry either full-duplex serial or Ethernet traffic. Only one type of traffic can be carried at a time and both ends of the link must be set to the same selection. Configure the channel with the command

```
> channel serial
```

or

> **channel ethernet**

as desired.

2.2.3.2 Serial Port

The DB-25 connector carries the serial data traffic. It may be configured through the software for either synchronous or asynchronous operation at a variety of speeds, and for either EIA-530 or EIA-232 drivers and receivers.

The serial port should be properly configured before connecting to external equipment.

2.2.3.2.1 Speed

Serial data may be either synchronous at 64 or 128 Kbps, or asynchronous at 300 to 19200 bps. The speed selection automatically determines whether the protocol is synchronous or asynchronous.

Both ends of the link must be set to the same speed.

The speed and protocol may be set to 64 or 128 Kbps synchronous with the command:

> **speed 64**

or

> **speed 128**

The speed and protocol may be set to 300 to 19200 bps asynchronous with the command:

> **speed 300**

where the 300 may be replaced with 600, 1200, 2400, 4800, 9600, 14400, or 19200 as desired.

2.2.3.2.2 Clock Source

Synchronous serial mode requires the use of a data clock for both receive data and transmit data. The receive data clock is always derived from the received signal and is provided by the modem. The transmit clock, however, may be provided by one of three sources. With the clock set to internal, the modem supplies a clock at 64 Kbps or 128 Kbps depending on the speed setting. With the clock set to external, the customer equipment supplies a 64 or 128 Kbps clock that should match the speed setting. With the clock set to loop, the receive clock is also used for the transmit side.

The clock mode of the modem at each end of the link must be configured appropriately depending on the clock mode of the customer equipment to which it is attached. For example, if the customer equipment is generating the transmit clock, the modem must use the external clock mode. On the other hand, if the customer equipment is expecting the clock to be provided by the modem, then the modem must be set to internal clock mode. Each end of the link may be configured independently to use internal, external, or looped clock, except that using looped mode at both ends of the link is not recommended.

The clock source may be set with one of the commands:

> **clock int**

or

> **clock ext**

or

```
> clock loop
```

2.2.3.2.3 Interface Type

The serial interface may use either EIA-232 or EIA-530 drivers and receivers. Either type of interface may be used with both synchronous and asynchronous data.

Each end of the link may be configured independently.

The interface type may be configured with the command

```
> interface 232
```

or

```
> interface 530
```

2.2.3.3 *Data Sharer*

The rack-mount unit (4050R) includes a built in data sharer function where two separate EIA-530/232 ports are provided, designated ports A and B.

At any given time one of the ports will be the 'selected' port. The currently selected port depends on the status of the request-to-send (RTS) line on the two ports. If only one port has RTS asserted, that port will be the selected port. If both ports, or neither port, has RTS asserted, then port A is given priority and will be the selected port. The RTS line from either port may be enabled or disabled if desired.

Transmitted data (TD) and the external transmit clock (TSET) used in synchronous mode are always taken from the selected port. The remote and local loopback signals (RL and LL) are also taken from the selected port. Clear-to-send (CTS) will only be asserted on the selected port.

The system may be configured to send receive data to both ports or to the selected port only. The data-set-ready (DSR), receive clock (RSET), and data-carrier-detect (DCD) are always present on both ports.

2.2.3.3.1 RTS Enable

Enable the RTS signal on one or both ports as required. If a port is unused and has no cable connected, it is strongly recommended that the corresponding RTS signal be disabled. The RTS enable may be set with one of the following commands:

```
> rtSENable a
```

or

```
> rtSENable b
```

or

```
> rtSENable both
```

2.2.3.3.2 RX Data Output

Enable sharer data output on both ports or only on the selected port, as desired, with one of the following commands:

```
> sharerout selected
```

or

```
> sharerout both
```

2.2.3.4 Ethernet Data Port

The Ethernet data port requires no configuration. When the Ethernet channel is selected, the link speed is automatically set to 128 Kbps.

The Ethernet data port attempts to transport any valid Ethernet packet it receives to the other end of the link. No assumption is made about higher layer protocols and, in particular, there is not even the assumption that Internet Protocol (IP) is used. The Ethernet data port needs no IP address, netmask, or default gateway.

Since the modem link is slower than the Ethernet network, packets may arrive at the port faster than they can be transmitted across the link. In this case the modem will buffer and transmit as many packets as possible but some packets may be lost. This is consistent with ethernet's "best effort" deliver policy. If guaranteed delivery is required, a higher layer protocol such as Transmission Control Protocol (TCP) will assure delivery even when there is packet loss due to congestion or mis-matched link speeds.

2.2.4 Remote Management Port Configuration

The Ethernet Remote Management System (RMS) port is used for Simple Network Management Protocol (SNMP), software updates, system message logging, and setting the system clock. All of these functions are optional and, if they are unused, the port may be left un-configured and unconnected.

If any of these features are desired, it may be necessary to configure the port before it is connected to the local network. Failure to properly configure the port may cause the port to not operate and/or interfere with the operation of other devices on the local network.

A network configuration summary may be displayed with the **netconfig** command.

2.2.4.1 DHCP

The IP parameters of the interface may be automatically configured using a Dynamic Host Configuration Protocol (DHCP) server on the local network. The DHCP server will typically configure the IP address and netmask, default gateway, and Domain Name Servers (DNS).

To enable use of a DHCP server, use the command:

```
> dhcp on
```

To disable the use of a DHCP server, use the command:

```
> dhcp off
```

2.2.4.2 IP Address / Netmask

Each device on the local network requires a unique IP address. If the IP address and netmask are configured with DHCP, the manual IP address and netmask are not used.

To set the IP address, use the command

```
> ip aaa.bbb.ccc.ddd
```

where aaa.bbb.ccc.ddd is the desired IP address in the usual "dotted quad" format.

To set the netmask, use the command

```
> netmask aaa.bbb.ccc.ddd
```

where aaa.bbb.ccc.ddd is the desired netmask in the usual “dotted quad” format.

2.2.4.3 Default Gateway

When the local network includes one or more routers connecting to other networks, a default gateway should be specified to indicate which is the most likely router to handle traffic to arbitrary IP addresses.

If DHCP is enabled, this manual setting is not used.

To set the default gateway, use the command

```
> gateway aaa.bbb.ccc.ddd
```

where aaa.bbb.ccc.ddd is the IP address of the default router in the usual “dotted quad” format.

2.2.4.4 DNS Servers

If either the timeserver or loghost (see following) are specified by name rather than IP number then a DNS is needed to resolve the name.

If DHCP is enabled, then the DNS may be set automatically. However, if DHCP is disabled or if it does not designate a DNS server, then the manual setting will apply.

Two DNS server may be specified, in which case the secondary server is used in the event the primary server is unavailable.

To set the DNS server use the commands:

```
> dns pri aaa.bbb.ccc.ddd
```

```
> dns sec eee.fff.ggg.hhh
```

2.2.4.5 Timeserver

The modem does not have real-time clock hardware that will allow it to maintain a time reference when powered off. However, during its startup procedure it will attempt to contact a timeserver on the network to set its clock to the actual time. The time is only used for message logging and other diagnostic purposes and a correct time is merely a convenience. Consequently, the availability of a timeserver is completely optional.

The factory set timeserver is us.pool.ntp.org, which refers to a collection of public timeservers generally available on the Internet. A DNS server must be available to resolve that timeserver name into an IP address.

The protocol used to set the time is NTP (network time protocol). Any NTP server may be used as a timeserver.

To change the timeserver use the command:

```
> timeserver aaa.bbb.ccc.ddd
```

or

```
> timeserver hostname.domainname
```

where aaa.bbb.ccc.ddd is the IP address of the timeserver in the usual “dotted quad” format, or hostname.domainname is the hostname and domain name. Note that there is no default domain name so it must be explicitly specified with the hostname.

2.2.4.6 Loghost

The modem can send system log messages to a specified loghost. This feature is mainly intended for debugging purposes and a loghost is completely optional. Normally only error messages and a limited number of startup messages are logged.

The “syslog” protocol is used to send the messages. Any host system with a syslog facility may be used to collect the messages. Most Unix and Linux system have syslog capability and there are both free and commercial syslog programs for Windows.

Specifying the loghost with an IP number of 0.0.0.0 or with a name of “none” disables the syslog messages. The system is configured at the factory with the syslog messaging disabled.

To set a loghost use the command

```
> loghost aaa.bbb.ccc.ddd
```

or

```
> loghost hostname.domainname
```

where aaa.bbb.ccc.ddd is the IP address of the loghost in the usual “dotted quad” format, or hostname.domainname is the hostname and domain name of the loghost. Note that there is no default domain name so it must be explicitly specified with the hostname.

2.3 Factory Configuration

The modems are set at the factory to the following standard configuration:

Dash.....as indicated on the label
Muteon (no output)
TX Frequency
-15096.0 MHz
-25145.0 MHz
RX Frequency
-15145.0 MHz
-25096.0 MHz
Modulationon
TX Power+14 dBm
Interleave0
RSL Threshold-110 dBm
Temp Alarm Threshold50°C
Channel.....serial
Speed64 Kbps synchronous
TX Clock
-1looped
-2internal
Interface.....EIA-530
Mode.....point-to-point
Loopback.....off
Administrator accountadmin (no password)
Hostname.....hostname
DHCPon
IP0.0.0.0
Netmask.....255.255.255.0
Gateway.....0.0.0.0
DNS
primary0.0.0.0
secondary0.0.0.0
Timeserver.....us.pool.ntp.org
Loghost.....0.0.0.0

Modem 4050R only:

Rtsenableboth
SharerOut.....both

3 Monitoring Operation

3.1 Activity Indicators

When there is serial data present at the EIA-530/232 data port, the TX and RX status LEDs flash to indicate the presence of transmitted and received data respectively.

Each LED flashes when the first data is detected and continues to flash at a predetermined rate as long as data is being detected. In synchronous mode, only changes in the data are detected so that a continuous stream of a single character will not cause the LED to flash.

In addition the DAT status LED flashes to indicate a data error has been detected.

Note: the status LEDs flash to indicate the corresponding activity but will be on solid to indicate an alarm. Refer to the following section for more information on alarms.

3.1.1 Transmit Activity Indicator

The TX status indicator flashes when data input is present at the EIA-530/232 port whether or not this data is transmitted. Certain conditions, such as if loopback is on or the radio is muted, will prevent the data from being transmitted even though the TX indicator is flashing.

3.1.2 Receive Activity Indicator

The RX status indicator flashes when data output is present at the EIA-530/232 port.

3.1.3 Data Error Indicator

The DAT status indicator flashes whenever an uncorrectable error occurs in the received data. This indicates a block of data was corrupted beyond what is correctable by the error correction algorithm. This is not normal and these events should be extremely rare in a normally operating link.

3.2 Alarms

The modem detects various abnormal conditions and generates an alarm to alert operators to the condition. The alarm conditions are grouped in to four categories: system, data, transmit, and receive alarms. Each category is associated with a status LED on the front and rear panels and with a solid-state relay contact closure. The specific conditions that generate each alarm are described below.

The system alarm status LED is green and is normally illuminated. It is extinguished when there is a system alarm or when any of the other alarm categories are asserted. Thus a no-alarm condition is easily identified by the green system LED on the panel being illuminated. Conversely, an alarm condition is easily identified by the green status LED being extinguished.

The other three alarm categories have a corresponding amber status LED that illuminates when an alarm condition is detected. Multiple alarm conditions may be present so more than one alarm LED may be illuminated.

Each of the four alarm categories also has a corresponding solid-state relay contact closure. The system alarm contact closure is normally closed while the other three contact closures are normally open.

The alarm status may be examined with the **alarm** command that displays the specific condition generating an alarm, if any. The **alarm** command will also indicate the cause of any transient alarm that may have occurred but is now cleared.

3.2.1 System Alarms

High Modem Temperature	The temperature on the modem board exceeds the set high temperature threshold. The factory set threshold is 50°C but may be independently adjusted as desired.
High RF Temperature	The temperature of the RF module exceeds the set high temperature threshold. The factory set threshold is 50°C but may be independently adjusted as desired.
High PA Temperature	The temperature of the transmitter power amplifier exceeds the set high temperature threshold. The factory set threshold is 50°C but may be independently adjusted as desired.

3.2.2 Data Alarms

No Frame Lock	The modem is not able to achieve frame lock on the incoming data. No frame lock may indicate a poor receive signal or mismatched configuration settings between the two ends of the link.
---------------	---

3.2.3 Transmit Alarms

Muted	The transmitter is muted because of a configuration problem or a transmit synthesizer problem.
Synthesizer Out of Lock	The transmit synthesizer is out of lock. This may indicate an unconfigured or misconfigured transmitter, or a hardware failure.
No Transmit Power	No transmit power is detected.
Low Transmit Power	The detected transmit power reading is less than 80% of its nominal value.

3.2.4 Receive Alarms

Synthesizer Out of Lock	The receive synthesizer is out of lock. This may indicate an unconfigured or misconfigured receiver, or a hardware failure.
AGC Out of Lock	The automatic gain control system is not able to achieve a suitable receive signal level.
Low RSL	The receive signal level is below the set threshold level. The RSL is not a measured value but is inferred from the AGC system. The threshold level may be set by the administrator and should be set to an appropriate value depending on the expected operating conditions.

3.3 Status

Useful status information may also be displayed by various commands including **rs1**, **stats**, **temp**, **linestat**, and **ifinfo**.

The **rs1** command continuously displays near real-time receive signal strength and may be used to “peak” the antenna positioning when installing the system.

The **stats** command displays statistics about the performance of the Forward Error Correction (FEC) mechanism. This information may be helpful in evaluating the quality of the RF link and the operating margin.

The **temp** command displays the current and peak temperatures measured in the RF module, the power amplifier, and the processor/modem.

The **linestat** command displays the current status of the modem control signals on the EIA-530/232 data port(s).

The **ifinfo** command displays current information about the ethernet ports, including hardware address, IP address, and some performance statistics.

See the description of each command below for details.

4 Local Craft Interface

4.1 Craft Interface Terminal Port

The modem has a Craft Interface Terminal (CIT) port that is used to configure it and monitor its operation. The user interface is a text-based “command line” style so that it is compatible with most laptop Personal Computers (PCs) and Personal Digital Assistants (PDAs). Terminal emulator software such as “HyperTerminal” or equivalent is required for the PC or PDA.

The physical interface is 9600 baud serial with a 9 pin female D-sub connector (DE-9F). The connector is configured as Data Communication Equipment (DCE) so a straight thru cable is used to connect to a typical PC or PDA.

In the following descriptions the authorization designation “RO” indicates the command is “read only” meaning the current value can be displayed but not changed. The designation “RW” indicates the command is “read / write” and the value can be both displayed and changed.

When a command is entered without an optional parameter, the current value is displayed. When the command is entered with a parameter, the value will be changed to the specified value.

In the following usage descriptions, optional parameters are shown enclosed in square brackets []. Alternative parameters are shown in angle brackets < > and separated by a vertical bar. Unless otherwise noted, only one of the alternatives should be entered. Neither the angle brackets nor the vertical bar should be entered as part of the command.

4.2 Commands

4.2.1 accounts

Login Accounts

Usage: accounts

Authorization: Operator RO; Administrator RO

Display a list of existing login account names and the account type.

4.2.2 agc

Automatic Gain Control

Usage: agc

Authorization: Operator N/A; Administrator RO

Display the AGC on/off setting.

4.2.3 agcstatus

Status

Usage: agcstatus

Authorization: Operator RO; Administrator RO

Display information about the operation of the agc function. Probably only useful to the factory for debugging purposes.

4.2.4 alarms**Display Alarms**

Usage: alarms

Authorization: Operator RO; Administrator RO

Display alarm conditions, if any. Alarms that have been asserted since the last time this command was issued but are now de-asserted will be marked as “cleared.” This feature allows transient alarm condition to be “remembered” and more easily identified.

4.2.5 apc**Automatic Power Control**

Usage: apc

Authorization: Operator N/A; Administrator RO

Display the APC on/off setting. Note: this setting is normally ‘off.’

4.2.6 channel**Select Data Channel**

Usage: channel [<serial|ethernet>]

Authorization: Operator RW; Administrator RW

With no argument, displays the current data channel. Otherwise sets the data channel to the specified value.

The modem may carry either serial data or 10Base-T Ethernet data. A link speed of 128 Kbps is automatically selected when Ethernet traffic is being carried.

4.2.7 clear**Clear Screen**

Usage: clear

Authorization: Operator RW; Administrator RW

Clear terminal screen.

4.2.8 clock**Clock Mode**

Usage: clock [<int|ext|loop>]

Authorization: Operator RW; Administrator RW

Display or set the clock mode.

The clock mode is only applicable to synchronous communications. The synchronous transmit data may be aligned to a clock provided by the modem (“internal” clock), by the Data terminal Equipment (DTE) (“external” clock), or by the receiver (“looped-back” clock). The proper choice of clock mode depends on the requirements of the DTE.

With no argument, display the current clock mode. With an argument, set the clock mode to “int,” “ext,” or “loop.”

4.2.9 config

Configuration

Usage: config

Authorization: Operator RO; Administrator RO

Show current configuration settings summary.

4.2.10 dash

Dash Variation

Usage: dash [*<1|2>*]

Authorization: Operator RO; Administrator RW

Display or set “dash” variation.

There are two variations for the RF modem: one transmits on a higher frequency and receives on a lower frequency, and the other is the opposite. A link consists of one modem of each variation so that the receive frequency of each one can be tuned to the transmit frequency of the other. These two variations are called “dash one” and “dash two.”

A modem may be physically changed in the field from dash one to dash two, or vice versa, by following a specified procedure. After physically changing the modem, this command must be used to properly configure the software.

Note: this change requires opening the unit and may invalidate the warranty. Please consult the factory before making this change.

With no argument, display the current dash number setting. With an argument of “1” or “2” set the dash number as specified. When the dash number is changed, if there are valid transmit and receive frequencies set, then the frequencies are swapped so that the same frequencies are retained in their correct subbands.

4.2.11 delaccount

Delete Login Account

Usage: delaccount *name*

Authorization: Operator N/A; Administrator RW

Delete the named login account. Deleted accounts can not be undeleted, however they can be recreated although the password will be reset when the account is created.

4.2.12 dhcp

DHCP Enable

Usage: dhcp [*<0|1>*] [*<nlylofflon>*]

Authorization: Operator RO; Administrator RW

With no argument displays the current DHCP enable setting. Otherwise sets the DHCP enable to the specified value.

DHCP is a protocol that permits an Ethernet device to have its IP port configuration set automatically. When DHCP is enabled, at startup the modem will request IP configuration information from a DHCP server. If DHCP is

enabled the customer is responsible for providing a DHCP server that will supply the necessary configuration information or the Ethernet port will not work.

If DHCP is disabled, the IP number, netmask, gateway, and DNS configuration must be set manually.

Note: the 0/1 refers to the RMS Ethernet port (0) or the payload Ethernet port (1). Although there is a setting for the payload port, it is not used. The default port is 0, however, so entering a 0 or 1 is unnecessary and is only documented for the sake of completeness.

4.2.13 dhcpinfo

DHCP Information

Usage: dhcpinfo

Authorization: Operator RO; Administrator RO

Display ethernet interface information resulting from DHCP configuration. The information includes IP address, network and netmask values, broadcast address, gateway address, domain, domain name server, MAC address, and lease time.

If DHCP is not enabled or was not successful in configuring the interface, a message will be printed indicating no information is available.

4.2.14 dns

Domain Name Server

Usage: dns [<prlsec>] [nnn.nnn.nnn.nnn]

Authorization: Operator RO; Administrator RW

With no argument, displays the IP address of the domain name server(s). Otherwise sets the domain name server address to the specified value.

A domain name server, or DNS, is required for the RMS Ethernet port to locate other networked systems by name. It is possible to set a primary and a secondary name server. If not specified, primary is the default.

If DHCP is enabled, the DNS should be set automatically.

A DNS setting is optional. If it is not needed, an IP number of 0.0.0.0 may be entered.

4.2.15 gateway

Network Gateway

Usage: gateway [<nnn.nnn.nnn.nnnlhostname.domain>]

Authorization: Operator RO; Administrator RW

With no argument, displays the default IP gateway. Otherwise sets the default gateway to the specified value.

To communicate beyond the local network, the IP communication must go through an IP router. This command allows a default router to be specified to handle any communication beyond the local network.

The gateway may be specified as a “dotted quad” IP number (nnn.nnn.nnn.nnn) or as a hostname (and domain). If specified as a hostname, a DNS server must be available to resolve the name into an IP number.

4.2.16 help / ?

Help

Usage: help [<radiodatalink|network|admin|all>]

Usage: ? [<radiodatalink|network|admin|all>]

Authorization: Operator RO; Administrator RO

Display brief help information about available commands. Help without an argument displays the top level help screen. With an argument, displays help screen for commands related to a specific topic:

radio	radio configuration and performance
datalink	data channel configuration
network	network configuration
admin	administrative commands

4.2.17 hostname

Hostname

Usage: hostname [hostname]

Authorization: Operator RO; Administrator RW

With no argument, displays the network hostname for this modem. Otherwise sets the hostname to the specified value.

4.2.18 ident

Identify

Usage: ident

Authorization: Operator RO; Administrator RO

Display product identification information.

4.2.19 ifinfo

Ethernet Interface Information

Usage: ifinfo [<eth0|eth1>]

Authorization: Operator RO; Administrator RO

Display current ethernet interface information including hardware address (MAC address), IP address if any, status, and statistics.

4.2.20 interface

Interface Driver

Usage: interface [<232|530>]

Authorization: Operator RO; Administrator RW

Display or set the interface driver/receiver type.

The interface drivers and receivers may be configured to either EIA-232 (single ended) or EIA-530 (differential) standards. Either style of driver may be used with either the asynchronous or synchronous protocol.

4.2.21 interleave

Interleave Data Blocks

Usage: interleave [<0|1|2|3|4|5|6>]

Authorization: Operator RO; Administrator RW

With no argument, displays the current interleave depth. Otherwise set the interleave depth to the specified value.

Data blocks may be interleaved to improve the error performance in the presence of certain kinds of noise and interference. The optimum interleave depends on the characteristics of the noise and interference and selecting the optimum interleave depth is beyond the scope of this document.

Increasing the interleave depth increases the latency of the link.

Depth of 0 and 1 are equivalent and mean interleaving is off.

4.2.22 ip

Internet Protocol Address

Usage: ip [<0|1>] [nnn.nnn.nnn.nnn]

Authorization: Operator RO; Administrator RW

With no argument, display the current manual IP address. Otherwise, set the manual IP address to the specified value.

The IP address is required for the RMS Ethernet port to communicate. If DHCP is disabled then the IP address must be set manually using this command. A unique address must be assigned to each device on the network.

If DHCP is enabled, this setting is ignored. The value reported here DOES NOT represent the IP address established by the DHCP server.

Note: the 0/1 refers to the RMS Ethernet port (0) or the payload Ethernet port (1). Although there is an IP address setting for the payload port, it is not used. The default port is 0, however, so entering a 0 or 1 is unnecessary and is only documented for the sake of completeness.

4.2.23 linestat

Display Serial Line Status

Usage: linestat

Authorization: Operator RO; Administrator RO

Display the status of the modem control signals on the EIA-530/232 port(s).

4.2.24 loghost

Loghost Address

Usage: loghost [<nn.nn.nn.nnn|hostname.domain>]

Authorization: Operator RO; Administrator RW

With no value specified, display the current setting of the loghost. Otherwise set the loghost to the specified value. The loghost may be specified as a "dotted quad" IP address, or as a hostname and domain. The change will take effect when the system is restarted.

Specifying the loghost with an IP number of 0.0.0.0 or with a name of “none” disables the syslog messages. The system is configured at the factory with the syslog messaging disabled

The modem will send system error messages to the specified remote loghost on UDP port 514 using the “syslog” protocol. Use of this feature is completely optional, although it may be useful for monitoring or troubleshooting since a system console is not provided.

Any host system with a syslogd facility may be used to collect the messages. Most Unix and Linux system have syslogd capability and there are both free and commercial syslogd programs for Windows. (See, for example, <http://www.kiwisyslog.com>.)

4.2.25 loop

Loopback Mode

Usage: loop [☐|☐|n|y|off|on>]

Authorization: Operator RW; Administrator RW

Display or set the current loopback mode.

With no argument, displays the current loopback setting. With an argument of 0, n, or “off” sets the loopback to off. With an argument of 1, y, or “on” sets the loopback mode to on.

There are three loopback functions: local, remote, and traffic. Local loopback connects the serial data port output (RD) to the serial port input (TD). This is useful for testing the data interface lines, receivers, and drivers.

Remote loopback connects the receive serial data to the transmit serial data. This echos received data back to the sender where it can be checked for correctness, for example with a bit error rate tester (BERT).

4.2.26 mac

Media Access Control (MAC) Address

Usage: mac [☐|☐|>]

Authorization: Operator RO; Administrator RO

Display the Ethernet port MAC address.

Every Ethernet device is required to have a unique MAC or “hardware” address. This address is assigned by the manufacturer and is set at the factory.

The RMS and payload Ethernet ports have separate MAC addresses. The 0 or 1 will select which is displayed. If not specified, the RMS port (0) is displayed.

4.2.27 mod

Modulation

Usage: mod [☐|☐|n|y|off|on>]

Authorization: Operator RO; Administrator RO

With no argument, displays the current modulation setting. With an argument of 0, n, or “off” sets the modulation to off. With an argument of 1, y, or “on” sets the modulation to on.

4.2.28 multipoint

Multipoint Handshaking

Usage: multipoint [<0|1|nly|off|on>]

Authorization: Operator RW; Administrator RW

With no value specified, display the current multipoint setting. Otherwise, set the multipoint setting to the specified value. Multipoint on indicates point-to-multipoint mode; multipoint off indicates point-to-point mode.

The modems support point-to-point and point-to-multipoint communication modes. In point-to-multipoint mode, only one of the multipoint modems may transmit at any given time. This is controlled by the RTS (request-to-send) control line at the EIA-530/-232 DB-25 port.

When a multipoint modem has permission to transmit, it should assert RTS and wait for the modem to respond by asserting CTS (clear-to-send).

In multipoint mode the RF transmitter will be unmuted when RTS is asserted and, after delay to allow the link to be established, CTS will be asserted to indicate it is okay to send data. The transmitter will be muted when RTS is negated.

Arbitration among the multipoint modems for access to the link is a higher level network function and the responsibility of the customer.

Multipoint mode does not affect the operation of the receiver. The receiver is on whether or not the multipoint modems is transmitting and all multipoint modems may receive simultaneously.

4.2.29 mute

Mute the RF output

Usage: mute [<0|1|nly|off|on>]

Authorization: Operator RO; Administrator RW

Display or set the mute state.

With no argument, displays the current mute setting. With an argument of 0, n, or off sets the mute to “off” (enables RF output). With an argument of 1, y, or on sets the mute to “on” (disables RF output).

4.2.30 netconfig

Network Configuration Summary

Usage: netconfig

Authorization: Operator RO; Administrator RO

Display the current network configuration summary.

4.2.31 netflash

Update Software via the Network

Usage: netflash [-ift] host filename

or netflash [-if] http://website/filename

Authorization: Operator N/A; Administrator RW

Update the modem and/or application software.

This command will read a new software file via the RMS network connection using HTTP, FTP or TFTP. If the file is successfully downloaded as determined by checksum, the new file will be written to the program FLASH memory and will be run the next time the system is started.

The first form of the command above will use FTP unless the `-t` option is used, in which case TFTP will be used. The name of the FTP or TFTP server is specified by the 'host' parameter, which may be either an IP number or a host name. If a host name is used the name must be resolvable by DNS.

The second form of the command will use the HTTP protocol. The 'website' may be a web server name (resolvable by DNS) or an IP number.

If updating the modem software, the `-f` option must be specified. If updating the application and operating system software, do not use the `-f` option.

The system checks that the file being loaded contains the proper software and that the version is later than the currently installed version. To ignore the version number check, use the `-i` option, which is primarily useful for reverting to an earlier version of the software.

After loading new software, it is necessary to cycle power to load the new software.

If the software ever fails a consistency check at power up, either because the new software failed to load correctly or because of corruption or hardware failure, the system will automatically revert to a backup copy of software originally loaded at the factory. The backup copy of the software cannot be updated except at the factory.

4.2.32 netmask

Network Mask

Usage: netmask [`<0|1>`] [nnn.nnn.nnn.nnn]

Authorization: Operator RO; Administrator RW

With no value specified, display the current network mask. Otherwise set the network mask to the specified value. The change will take effect when the system is restarted.

The IP address consists of a "network" portion and a "host" portion. The network mask defines how much of the address is used for each one. A typical value for the network mask is 255.255.255.0.

If DHCP is enabled, this setting is ignored. The value reported here DOES NOT represent the network mask established by the DHCP server.

Note: the 0/1 refers to the RMS Ethernet port (0) or the payload Ethernet port (1). Although there is a network mask setting for the payload port, it is not used. The default port is 0, however, so entering a 0 or 1 is unnecessary and is only documented for the sake of completeness.

4.2.33 newaccount**Create Login Account**

Usage: newaccount name type

Authorization: Operator N/A; Administrator RW

Create the named login account. Account names must begin with a letter, must be no more than 16 characters, and must be unique. Account names are case sensitive. Only the characters A-Z, a-z, 0-9, dash, and underbar are allowed.

4.2.34 passwd**Set Passwords**

Usage: passwd [account]

Authorization: see below

Change login password. If no account name is specified, change the password for the currently logged in account. If an account is specified, change the password for that account. Only administrators can change the password for another account. Operators can only change their own password.

The new password will be solicited twice and the two entries are required to match in order to catch typing errors.

Passwords are case sensitive. New passwords are subjected to a series of tests designed to reject passwords that are too simple and/or easy to guess. Passwords must have at least characters. Those with two or more numerals, a mixture of uppercase and lowercase letters, and some punctuation are more likely to be accepted.

4.2.35 rsl**Received Signal Level**

Usage: rsl

Authorization: Operator RO; Administrator RO

Display the current received signal level.. This display is updated continuously until the return/enter key is pressed.

4.2.36 rslthr**RSL Alarm Threshold**

Usage: rslthr [-nnn.n]

Authorization: Operator RO; Administrator RW

Display or set the received signal level alarm threshold.

If the RSL falls below the specified value, a low received signal alarm is declared.

Without an argument, display the current RSL threshold.

With a numeric argument, sets the RSL alarm threshold to -nnn.n dBm.

4.2.37 rtsenable**Data Sharer RTS Enable or Disable**

Usage: rtsenable [<both|alblnone>]

Authorization: Operator RW; Administrator RW

Display or set the enable for the EIA-530/232 data port request-to-send (RTS) inputs. If no data sharer is present, this command is not usable.

With the data sharer, the currently selected port is a function of the RTS signals on the two ports. For a port to contend for access, its RTS signal must be enabled.

Without an argument, display the current RTS enable setting.

With an argument, sets the RTS enables to port a, port b, both ports, or neither port as specified.

4.2.38 rxfreq

Receive Frequency

Usage: rxfreq [ffff.f]

Authorization: Operator RO; Administrator RW

Display or set the receive frequency.

With no argument, display the current receive frequency.

With a numeric argument, set the frequency to “ffff.f” MHz. The frequency may be specified in 0.1 MHz (100 KHz) steps. The minimum and maximum frequency depends on the dash variation of the modem:

DASH	MINIMUM	MAXIMUM
-1	5140.0 MHz	5150.0 MHz
-2	5091.0 MHz	5101.0 MHz

4.2.39 sharer

Data Sharer Available

Usage: sharer [<yes|no>]

Authorization: Operator RW; Administrator RW

Display or set whether a data sharer is present in the system.

Without an argument, display whether the sharer exists. This is generally determined automatically when the system powers up.

With an argument, override the automatically determined value. This is only intended for testing purposes and not for normal operation. Setting this to ‘no’ will be persistent and will override the automatic setting. Setting this to yes will only override the automatic setting until the system is power cycled.

The setting should always be set to yes for normal operation.

4.2.40 sharerout

Data Sharer Output Selection

Usage: sharerout [<both|selected>]

Authorization: Operator RW; Administrator RW

Display or set how received data is to be output on the EIA-530/232 data sharer ports. Received data may be output on both ports all the time independent of which port is the currently selected port, or may be output only on the currently selected port.

Without an argument, display the current sharer output setting.

With an argument, sets the sharer output to both ports or only the selected port as specified.

4.2.41 speed

Set Interface Speed

Usage: speed [<300|600|1200|2400|4800|9600|19200|64|128>]

Authorization: Operator RW; Administrator RW

Display or set the interface speed.

With no argument, display the current interface speed.

With an argument, set the interface speed to the specified value. If the specified speed is “64” or “128” then the speed is set to 64,000 or 128,000 bits per second respectively and the protocol is set to synchronous. If the specified speed is 300 – 19200, the protocol is set to asynchronous.

If the speed is 128 Kbps synchronous, the link speed is also set to 128 Kbps. In all other cases the link speed is set to 64 Kbps.

4.2.42 stats

Error Correction Statistics

Usage: stats [<0|clr>]

Authorization: Operator RO; Administrator RW

With no argument, displays the error correction statistics. With an argument of zero or “clr” resets the statistics counters to zero.

The display includes the following information:

Elapsed seconds:	0	Seconds since the counters were last cleared. This time continues to increment whether or not a link is established.
Framing unlocked:	0	Records the number of times the data framing has lost lock. When framing is unlocked, data recovery and error correction are not functional and no useful data is communicated.
Total bytes:	0	Total bytes processed. This counts actual payload data in synchronous serial mode. In asynchronous serial and Ethernet modes this counter include “filler” bytes transmitted when there is no real data.
Corrected bytes:	0	The number of bytes corrected by the error correction logic.

Total blocks:	0	The total number of block processed by the error correction logic. A block contains up to 200 actual data bytes.
Errored blocks:	0	The number of blocks that had a detected error.
Uncorrected blks:	0	The number of blocks that had uncorrectable errors.
Corrected blocks:	0	The number of blocks that had corrected errors.

If there are any corrected blocks, a table is printed indicating how many blocks had one error, how many had two errors, and so forth.

4.2.43 syslog

System Logging

Usage: syslog [<nonelinfoldebug>]

Authorization: Operator RO; Administrator RW

With no argument, display the current system logging level. Otherwise, set the specified system logging level.

Multiple arguments may be specified, in which case each argument is applied in the order given. For example,

syslog none debug

will clear all optional logging and then enable logging of debug messages.

The modem sends system messages to a syslog host if one is specified. When a host is specified, the messages are sent using the “syslog” UDP protocol to port 514. Syslog messages are categorized in to multiple levels based on the severity of the condition and the importance of the message. The “info” and “debug” log level messages are optional and are disabled by default. All other messages levels are considered error messages and are always enabled.

The “info” and/or “debug” log levels may be useful for debugging in certain limited circumstances but should otherwise be off.

4.2.44 temp

Temperature

Usage: temp

Authorization: Operator RO; Administrator RO

Display the temperature of the modem, the RF module, and the power amplifier.

4.2.45 tempthr

Temperature Alarm Thresholds

Usage: tempthr [<rf|palmodem>] [nn]

Authorization: Operator RO; Administrator RW

If the temperature argument (nn) is absent, display the current temperature alarm thresholds. Otherwise sets the temperature alarm threshold to nn°C.

If one or more of the identifiers “rf”, “pa”, or “modem” is present the command applies only to the specified subsystem(s). If none is specified, the command applies to all subsystems.

An excessive temperature reading in the RF module, the power amplifier, or the modem board will generate a system alarm condition. The factory set threshold for the alarm is 50°C but this may be changed with this command.

4.2.46 testmode

Test LEDs, Fans, Relays

Usage: testmode [`<0|1|n|y|o|f|on>`]

Authorization: Operator RW; Administrator RW

With no argument, display the current state of the test mode. Otherwise set the test mode on or off as specified.

When the test mode is on, all the front and rear panel status LEDs will be turned on, both fans will be turned on, and the alarm relay states will be inverted.

The operation of the modem will be unaffected. If it is operational it will continue to operate when test mode is on. Note, however, that the inverted state of the alarm relays may externally affect the operation of the modem.

4.2.47 timeserver

Time Server

Usage: timeserver [`<nn.nn.nn.nnn|hostname.domain>`]

Authorization: Operator RO; Administrator RW

With no value specified, display the current setting of the time server. Otherwise set the time server to the specified value. The change will take effect when the system is restarted.

The time server may be specified as a “dotted quad” IP address, or as a hostname and domain.

When the system is started, it will attempt to contact the specified time server using Network Time Protocol (NTP) in order to set the modem’s internal time and date. An accurate time and date is optional and not necessary for the modem’s operation but it may be useful for timestamping messages in various system logs.

If the timeserver is not specified, or if the attempt to contact the timeserver is not successful, the modem’s time and date starts at 00:00 on 1-Jan-1970.

4.2.48 txfreq

Transmit Frequency

Usage: txfreq [`ffff.f`]

Authorization: Operator RO; Administrator RW

Display or set the transmit frequency.

With no argument, display the current transmit frequency.

With a numeric argument, set the frequency to “ffff.f” MHz. The frequency may be specified in 0.1 MHz (100 KHz) steps. The minimum and maximum frequency depends on the dash variation of the modem:

DASH	MINIMUM	MAXIMUM
-1	5091.0 MHz	5101.0 MHz
-2	5140.0 MHz	5150.0 MHz

4.2.49 txpower

Transmit Power Level

Usage: txpower [nn.n]

Authorization: Operator RO; Administrator RW

Display or set the current transmit power setting.

With no argument, displays the current transmit power setting. With a numeric argument, sets the transmit power level to nn.n. The power level is specified in dBm. Although tenths of a dBm may be specified on the command line, the power level will be set to the next lower 0.5 dBm setting. The power level may be set from a minimum of 0 dBm to a maximum of 30.0 dBm.

4.2.50 uptime

System Uptime

Usage: uptime

Authorization: Operator RO; Administrator RO

Display the system “uptime” – the time since the modem was first started. Also displays the modem’s current time (“wall” time) which will only be meaningful if it has been successfully set using a timeserver. See the timeserver command description.

Processor loading information is also shown but it is generally uninteresting.

4.2.51 version

Version

Usage: version

Authorization: Operator RO; Administrator RO

Display the version of the software modules in the modem.

5 SNMP - Simple Network Management Protocol

5.1 Overview

The Models 4050 and 4050R include an SNMPv3 agent with the User-based Security Module (USM) using MD5 pass phrases for authentication and DES encryption for privacy. In these systems both authentication and privacy options are permanently enabled and are required. SNMPv1 and SNMPv2 are not supported.

Authentication requires an account name and a pass phrase to gain access. There are no guest or anonymous accounts to permit access without a known account. In addition, the privacy feature requires a separate pass phrase for the encryption. Access is not possible without both the authentication and privacy pass phrases.

The SNMP accounts are separate from and independent of the user accounts used for local management. Creating, changing, or deleting a local user account has no effect on SNMP accounts, and vice versa.

The SNMPv3 implementation implements the view-based access control model (VACM). Each account is assigned a “view” of the MIB structure that defines which objects may be viewed and which may be changed. In the 4050 and 4050R there are two predefined views, once corresponding approximately to the administrator access available at the local management port, and one corresponding approximately to the operator access.

5.2 MIBs

There are three MIBs that are useful when accessing the Models 4050 and 4050R. Two of these are from Protium Technologies, Inc. and one is from the University of California at Davis (UCD). One of the MIBs from Protium Technologies, Inc. is general information and the other is specific to the Models 4050 and 4050R. The MIB from UCD is used for saving SNMPv3 user account information to non-volatile memory.

The Protium Technologies, Inc. MIBs are printed in the appendices of this document for reference. However, computer files of the MIBs are generally more useful than the printed versions. These may be downloaded from the Protium Technologies, Inc. web site at <http://www.protiumtechnologies.com/support/4050>.

The MIB files are:

PROTIUMTECH-MIB.mib

PROTIUMTECH-PRODUCTS-MODEL4050-MIB.mib

UCD-SNMP-MIB.txt

5.3 SNMP Tools

There are many SNMP tools (“MIB browsers”) available for Windows, Unix, Linux and other operating systems that may be used to access the agent in the modem. Some simple tools are command line based while many have graphical user interfaces, scripting capability, historical databases, and other features. Many are commercial products while others are freely available, or have limited versions that are freely available.

Any recommendation for a specific MIB browser is beyond the scope of this document. However, when selecting a browser be sure that it supports SNMPv3 since this is required. It will also be helpful if the MIB definition files for the 4050/4050R can be imported into the MIB browser.

5.4 Account Management

SNMPv3 user accounts are managed via SNMP itself. They are not accessible from the local management port.

When shipped from the factory, there is a predefined user that may be used for account management and to create additional user accounts. For security, the pass phrase on this predefined user should be changed to prevent

unauthorized access. New user accounts with administrative access may also perform account management, in which case the original factory defined user may be deleted.

The specific details of managing accounts will depend a lot on the particular MIB browser that is being used. The instructions below show command line examples that are probably unlikely to be used in practice. In any case, however, the following steps or their equivalent are necessary for user account management.

5.4.1 Creating a User

The procedure that is used by SNMP to create a new user account is (a) clone an existing user, (b) assign an existing set of access rights to the new user, (c) change the pass phrases of the new user, and (d) commit the changes to non-volatile memory.

5.4.1.1 Cloning a User

New users are created by cloning an existing user. The initial factory provided users (“admin” and “oper”) are configured with MD5 authentication and DES privacy encryption. Since cloning is the only way to specify which authentication and privacy protocols to use for a given user, all subsequent users will also have MD5 authentication and DES encryption.

Note: it is only possible to clone to a new user one time. Subsequent attempts to re-clone onto the same user will appear to succeed, but will be silently ignored. This somewhat unexpected behavior is mandated by the SNMPv3 USM specifications (RFC 3414). To recreate a user, it is necessary to first delete the existing user.

The following command clones the existing (factory defined) user “admin” to a new user named “newuser.” Each of the options in the command line is explained below.

```
snmpusm -v 3 -u admin -l authPriv -a MD5 -A password -x DES -X password \
192.168.1.64 create newuser admin
```

The following “common options” in the command line are necessary to access the SNMPv3 agent in the modem for any purpose. Some or all of these may be set as default values in the MIB browser so that it is not necessary to specify them each time.

-v 3	Use SNMPv3
-u admin	Use user account “admin” to access SNMP
-l authPriv	User account “admin” has both authentication and privacy
-a MD5	Use MD5 for authentication
-A password	Use “password” as the MD5 pass phrase. This is the factory set pass phrase. If the pass phrase has been changes as is recommended, the new pass phrase should be used here.
-x DES	Use DES encryption
-X password	Use “password” as the DES pass phrase. This is the factory set pass phrase. If the pass phrase has been changes as is recommended, the new pass phrase should be used here. The DES pass phrase may or may not be the same as the MD5 pass phrase.

The following options specify the actual function that is to be performed:

192.168.1.64	The IP number (or domain name resolvable to the IP number) of the RF modem. The actual value should refer to the target RF modem.
create	The desired USM function, i.e. create a new user

newuser	The name of the new user to create
admin	The name of the existing user from which to clone the new user. Any existing user may be used as the basis for the new user. Note: the new user will initially have the same pass phrases as the existing user.

5.4.1.2 Assigning Access Rights

Although a new user inherits the pass phrases of the cloned-from user, the new user does not inherit any access rights. Unless access rights are explicitly assigned, the new user will have none and will not be able to do anything useful.

The following command assigns the new user “newuser” to an existing group that gives the new user certain access rights. The available group names are “admingroup” and “opergroup” for administrator and operator access respectively.

```
snmpvacm [COMMON OPTIONS] createSec2Group 3 newuser groupname
```

The [COMMON OPTIONS] are those necessary to access SNMPv3 as described above.

The numeral “3” specified the USM security model.

5.4.1.3 Changing the Pass Phrase

When a new user is first created (cloned), the new user has the same pass phrases as the cloned-from user. The pass phrases of the new user should be changed immediately. Note that is necessary to know the existing pass phrase, i.e. the pass phrase of the cloned-from user, in order to change the pass phrase of the new user.

```
snmpusm -v 3 -u newuser -l authPriv -a MD5 -A password -x DES -X password \  
[-Ca] [-Cx] passwd OLD-PASSPHRASE NEW-PASSPHRASE
```

This command will change the pass phrase of the user issuing the command. It is issued as the “newuser” using the pass phrase of the cloned-from user (“password”). The “passwd” is the actual command to change the pass phrase, all the parameters prior to that are to authenticate the command.

If the **-Ca** or **-Cx** options are specified, then only the authentication or privacy keys are changed. If these options are not specified, then both the authentication and privacy keys are changed.

5.4.1.4 Committing Changes

After the user is created and access rights are assigned as described above, the user account will be active and may be tested to ensure that everything was specified correctly. However, the user is not automatically saved to non-volatile memory and will disappear if the system is powered off.

It is necessary to explicitly save the changes to non-volatile memory in order for them to remain after the system is powered off. This may be done after the changes are verified to be correct, and perhaps after creating multiple users.

Saving the user tables to non-volatile memory is done by simply writing “1” to a particular OID as in the following example:

```
snmpset [COMMON OPTIONS] .1.3.6.1.4.1.2021.100.13.0 i 1
```

The [COMMON OPTIONS] are those necessary to access SNMPv3 as described above. The letter “i” specifies the following value is an integer.

The numeric OID above corresponds to the following string:

.iso.org.dod.internet.private.enterprises.ucdavis.version.versionSavePersistentData.0

If the UCD MID is loaded into the MIB browser, the above may be accomplished by the simpler:

snmpset [COMMON OPTIONS] versionSavePersistentData.0 = 1

5.4.2 Changing a User’s Pass Phrases

The following command will change the pass phrase of the user issuing the command:

**snmpusm [COMMON OPTIONS] [-Ca] [-Cx] **
passwd OLD-PASSPHRASE NEW-PASSPHRASE

The [COMMON OPTIONS] are those necessary to access SNMPv3 as described above.

The “passwd” is the actual command to change the pass phrase. If the -Ca or -Cx options are specified, then only the authentication or privacy keys, respectively, are changed. If these options are not specified, then both the authentication and privacy keys are changed.

Note that the old pass phrase is required in order to set the new pass phrase. This means it is not possible to recover from a lost pass phrase by changing the pass phrase. The only recourse in this case is to delete and recreate the user.

After changing a pass phrase, it is necessary to explicitly save the change to non-volatile memory as described above in the section regarding creating a new user.

5.4.3 Deleting a User

Deleting a user account may be necessary when a user account is no longer needed, or in some cases to re-create the user in order recover a lost password.

Any user with administrator access rights may delete a user account. Users with operator access rights are not permitted to delete users.

snmpusm [COMMON OPTIONS] delete username

The [COMMON OPTIONS] are those necessary to access SNMPv3 as described above.

6 Specifications

System

Frequency Range	5091 - 5150 MHz
T/R Spacing	54 or 49 MHz
Capacity	64/128 kb/s
Occupied Bandwidth	100/200 kHz
Modulation Type	Modified Duobinary CPM
Forward Error Correction	Reed-Solomon
Interleaving	Selectable 0 - 6
Link Acquisition Time	Less than 5 seconds
Power Supply	Model 4050: 20 to 60 VDC, either polarity Model 4050R: 100-132 VAC, 60 Hz
Power Consumption	<30 Watts
System Gain @10 ⁻⁶ BER	128/126 dB
Operating Modes	Full/half Duplex

Transmitter

Transmitter Source	Fully Synthesized
Frequency Tolerance	< 1.5 ppm
Tuning Steps	0.1 MHz
Output Power	30 dBm
Power Adjustment Range	>20 dB, 0.5 dB Steps
Spectral Compliance	NTIA Spectrum Manual, Ch. 5
Tx Mute	<-50 dBm

Receiver

Receiver Source	Fully Synthesized
Frequency Tolerance	< 1.5 ppm
Tuning Steps	0.1 MHz
Rx Threshold @ 10 ⁻⁶ BER	-98/-96 dBm
Dynamic Range	> 70 dB
Maximum Input (without damage)	+10 dBm
Residual BER	<1x10 ⁻¹⁰

Interfaces

Data	EIA-530, EIA-232 (DB-25F, DCE) or IEEE 802.3 (RJ-45)
SNMP	IEEE 802.3 (RJ-45)
Local Craft Interface Terminal (CIT)	EIA-232, 9600 bps (DE-9F, DCE)
Alarms	8 pin mini-DIN, 4 form A contact pairs
Antenna	Type N

Unit Management and Diagnostics

Local CIT	Command line interface
SNMP	Version 3

Physical Characteristics

Unit Size	Model 4050: 1.8"H x 9.5"W x 12"D Model 4050R: 1.73"H x 17"W x 13.33"D
Weight	5.0 lb.

Environmental

Temperature Range

0 - 50 °C, 0 – 70 °C Reduced Tx Power

Humidity

0 - 95% non-condensing

Shock

per IEC-68-2-27

Vibration

per IEC-68-2-6

Safety

Model 4050R: EN60950

EMC

Immunity

per IEC 61000-4-2,3,5,6



Emissions

Compliant with FCC Part 15, Class A Devices


7 Connectors

7.1 Front & Rear Panels

7.1.1 Remote Unit



7.1.2 Rack-mount Unit



7.2 Pin-out Tables

7.2.1 Data Port

The following pin-out applies to the data port on a remote unit, and to both ports A and B on the rack-mount unit.

EIA-232			
PIN	NAME	SOURCE	FUNCTION
1	FG		Chassis Ground
2	TD	DTE	Transmit Data to Modem
3	RD	DCE	Receive Data from Modem
4	RTS	DTE	Request to Send to Modem
5	CTS	DCE	Clear to Send from Modem
6	DSR	DCE	Data Set Ready from Modem
7	SG		Signal Ground
8	DCD	DCE	Receive Line Signal Detect from Modem
9			
10			
11			
12			
13			
14			
15	TC	DCE	Transmit Clock from Modem
16			
17	RC	DCE	Receiver clock from Modem
18	LL	DTE	Local Loopback to Modem
19			
20	DTR	DTE	Data Terminal Ready to Modem
21	RL	DTE	Remote Loopback to Modem
22			
23			
24	TCE	DTE	External Transmit Clock to Modem
25			

EIA-530				
PIN	NAME	SOURCE	FUNCTION	Pairing
1	SHIELD		Shield Ground	
2	TD(A)	DTE	Transmit Data to Modem	14
3	RD(A)	DCE	Receive Data from Modem	16
4	RTS(A)	DTE	Request to Send to Modem	19
5	CTS(A)	DCE	Clear to Send from Modem	13
6	DCR(A)	DCE	DCE Ready from Modem	22
7	SG		Signal Ground	
8	RLSD(A)	DCE	Receive line Signal Detect from Modem	10
9	RSET(B)	DCE	Receive Clock from Modem	17
10	RLSD(B)	DCE	Receive Line Signal Detect from Modem	8
11	TSET(B)	DTE	Terminal Timing Clock to Modem	24
12	TSET(B)	DCE	Transmit Clock from Modem	15
13	CTS(B)	DCE	Clear to Send from Modem	5
14	TD(B)	DTE	Transmit Data to Modem	2
15	TSET(A)	DCE	Transmit Clock from Modem	12
16	RD(B)	DCE	Receive Data from Modem	3
17	RSET(A)	DCE	Receive Clock from Modem	9
18	LL	DTE	Local Loopback to Modem	
19	RTS(B)	DTE	Request to Send to Modem	4
20	DTR(A)	DTE	DTE Ready to Modem	23
21	RL	DTE	Remote Loopback to Modem	
22	DCR(B)	DCE	DCE Ready from Modem	6
23	DTR(B)	DTE	DTE Ready to Modem	20
24	TSET(A)	DTE	Terminal Timing Clock to Modem	11
25	TM	DCE	Test Mode	

NOTE 1: The RF modem is DCE and drives those signals that originate in the DCE

7.2.2 Craft Interface Terminal (CIT) Port

EIA-232		
PIN	NAME	ORIG
1	DCD	DCE
2	RD	DCE
3	TD	DTE
4	DTR	DTE
5	SG	
6	DSR	DCE
7	RTS	DTE
8	CTS	DCE
9	RI	DCE


NOTE 1: The RF modem is DCE and drives those signals that originate in the DCE

7.2.3 Alarm Relays

ALARMS		
PIN	NAME	STATE*
4	SYS1	NC
6	SYS2	
3	DAT1	NO
1	DAT2	
2	TX1	NO
5	TX2	
8	RX1	NO
7	RX2	

*Indicates contact status during normal operation

NOTE 1: Mating connector is male.



CONNECTOR MATING END VIEW

7.2.4 Ethernet

There are two 10Base-T Ethernet ports, one for management and one for carrying data. Both ports will auto-negotiate for either full- or half-duplex.

The connectors are standard RJ-45 and have automatic Media Dependent Interface Crossover (Auto-MDIX) capability for compatibility with MDI and MDIX equipment.

7.2.5 Power

7.2.5.1 Remote Unit

DC POWER		
PIN	NAME	POLARITY
Center	V1	+ or -
Sleeve	V2	- or +

NOTE 1: Mating connector is 2.5 mm x 5.5mm x 11mm female

NOTE 2: Both pins are isolated from chassis ground.

NOTE 3: Input voltage 24 to 48 VDC

7.2.5.2 Rack-mount Unit

The AC input connector is a standard IEC-320 C14 appliance inlet that mates to an IEC-320 C13 plug on the AC power cord.



8 Software Licenses

8.1 Open Source Software

The operating system used by the Model 4050 is uClinux 2.4. This is derived from the Linux 2.4 kernel, which is copyrighted by Linus Torvalds and others and licensed under the GNU General Public License (GPL) Version 2.

The C library used in the system is uClibc, which is licensed under the GNU Library General Public License (LGPL) Version 2.

The GNU General Public License and Library General Public License themselves are copyrighted by the Free Software Foundation.

The port of uClinux to the Xilinx Microblaze processor is primarily the work of John Williams, jwilliams@itee.uq.edu.au, and most (if not all) of that work is copyrighted by him. These modifications to the kernel are derivative work and are consequently also licensed under the GNU GPL V2.

Device drivers, which are also generally considered to be part of the kernel, are claimed to be derivative works thereof and, as such, come under the GNU GPL V2 license. This includes the device drivers written or modified by Protium Technologies, Inc. for the Xilinx SPI peripheral and for a specialized character device peripheral. Other device drivers are copyrighted by their respective authors, most notably by John Williams who is responsible for modifying the device drivers for the Microblaze peripherals, by Xilinx, and by others.

Standard Linux application programs provided with the system are copyrighted and licensed individually and separately from the kernel. Each application source directory should be consulted for the copyright and software license terms that apply to that application package.

Copies of the GNU General Public License and the GNU Library General Public License are reproduced in Appendix B for the reader's convenience. These are provided for reference only. The definitive licenses are those that accompany the source code.

Source code is available to legitimate owners of Model 4050 hardware in accordance with the GNU GPL, LGPL, and other applicable licenses. Requests for source code may be sent to Protium Technologies, Inc., 10 Bearfoot Road, Northborough, MA 01532.

8.2 Protium Technologies, Inc. Software License

The various applications embedded in to the equipment that specifically operate and manage the Model 4050, including the command line user interface application, are original works and are Copyright 2005, 2006 by Protium Technologies, Inc. and are licensed in binary form for use only with the Model 4050 RF Modem.

The Protium Technologies, Inc. Software License is located in Appendix B1.

9 Warranty and Service Information

Protium Technologies, Inc.'s standard warranty is one year from the date of delivery, provided that the warranty labels have not been broken. Breaking the seals or opening the modem without the expressed, written consent of Protium Technologies, Inc. will automatically void the warranty.

Protium Technologies, Inc.'s liability for a warranty failure applies only to the equipment provided by Protium Technologies, Inc. and excludes all other remedies, including, without limitation, incidental consequential damages. Protium Technologies, Inc. is not responsible for any lost data, revenue, or any consequential damages associated with a warranty or non-warranty failure.

In the event of a defect in or failure of the Protium Technologies, Inc. product, the customer shall contact Protium Technologies, Inc. regarding the warranty claim. Protium Technologies, Inc. warrants to rework or repair the product at the Protium Technologies, Inc. facility in Northborough, Massachusetts once it has been properly returned by the customer.

To process a warranty claim please contact Protium Technologies, Inc. at the following location:

Protium Technologies, Inc.
10 Bearfoot Road
Northborough, MA 01532
Phone: 508-393-3700
Facsimile: 508-393-3157
warranty@protiumtechnologies.com

Protium Technologies will periodically update the documentation on this product to provide guidance and clarification on common installation issues. Please check the Protium Technologies web site at <http://www.protiumtechnologies.com/support/4050> for the latest updates.

Appendix A Protium Technologies, Inc. MIBs

A.1 Protium Technologies, Inc. Enterprise MIB

```
PROTIUMTECH-MIB DEFINITIONS ::= BEGIN

--
-- Top-level infrastructure of the Protium Technologies, Inc. enterprise MIB tree
--
IMPORTS
    MODULE-IDENTITY, enterprises FROM SNMPv2-SMI;

protiumTech MODULE-IDENTITY
    LAST-UPDATED "200701311600Z"
    ORGANIZATION "Protium Technologies, Inc."
    CONTACT-INFO
        "Protium Technologies, Inc.
        10 Bearfoot Road
        Northborough MA 01532
        508-393-3700
        snmp-mib@protiumtechnologies"
    DESCRIPTION
        "Top-level infrastructure of the Protium Technologies, Inc. enterprise MIB tree"
    REVISION      "200701311600Z"
    DESCRIPTION
        "Contact info updated with new address and telephone"
    ::= { enterprises 23271 }

--
-- Net-SNMP enterprise-specific management objects
--
protiumTechRegistrations      OBJECT IDENTIFIER ::= {protiumTech 1}
protiumTechProducts          OBJECT IDENTIFIER ::= {protiumTech 3}
protiumTechNotificationPrefix OBJECT IDENTIFIER ::= {protiumTech 4}
protiumTechConformance       OBJECT IDENTIFIER ::= {protiumTech 5}
protiumTechExperimental      OBJECT IDENTIFIER ::= {protiumTech 9999}

--
-- A subtree specifically designed for private testing purposes.
-- No "public" management objects should ever be defined within this tree.
--
-- It is provided for private experimentation, prior to transferring a MIB
-- structure to another part of the overall OID tree
--
protiumTechPlaypen           OBJECT IDENTIFIER ::= {protiumTechExperimental 9999}

--
-- Notifications
--
protiumTechNotifications     OBJECT IDENTIFIER ::= {protiumTechNotificationPrefix 0}
protiumTechNotificationObjects OBJECT IDENTIFIER ::= {protiumTechNotificationPrefix 1}

--
-- Conformance
-- (No laughing at the back!)
--
protiumTechCompliances        OBJECT IDENTIFIER ::= {protiumTechConformance 1}
protiumTechGroups            OBJECT IDENTIFIER ::= {protiumTechConformance 2}

END
```

A.2 Protium Technologies, Inc. Model 4050 MIB

```

PROTIUMTECH-PRODUCTS-MODEL4050-MIB DEFINITIONS ::= BEGIN

IMPORTS
    MODULE-IDENTITY, OBJECT-TYPE, Integer32 FROM SNMPv2-SMI
    SnmpAdminString                               FROM SNMP-FRAMEWORK-MIB
    protiumTechProducts                           FROM PROTIUMTECH-MIB
    -- RowStatus, StorageType                     FROM SNMPv2-TC
    -- InetAddressType, InetAddress               FROM INET-ADDRESS-MIB
;

protiumTechModel4050 MODULE-IDENTITY
    LAST-UPDATED "200701311600Z"
    ORGANIZATION "Protium Technologies, Inc."
    CONTACT-INFO
        "Protium Technologies, Inc.
        10 Bearfoot Road
        Northborough MA 01532
        508-393-3700
        snmp-mib@protiumtechnologies"
    DESCRIPTION
        "MIB objects for the agent module of the Model 4050 RF Modem"
    REVISION      "200701311600Z"
    DESCRIPTION   "Revisions for Version 2 Hardware"
    ::= { protiumTechProducts 1 }

--
-- top level structure
--
protiumTechSystem          OBJECT IDENTIFIER ::= { protiumTechModel4050 1 }
    systemInfo              OBJECT IDENTIFIER ::= { protiumTechSystem 1 }
    systemConfig            OBJECT IDENTIFIER ::= { protiumTechSystem 2 }
    systemStatus            OBJECT IDENTIFIER ::= { protiumTechSystem 3 }
    systemStats             OBJECT IDENTIFIER ::= { protiumTechSystem 4 }
protiumTechAlarms          OBJECT IDENTIFIER ::= { protiumTechModel4050 2 }
    alarmInfo               OBJECT IDENTIFIER ::= { protiumTechAlarms 1 }
    alarmConfig             OBJECT IDENTIFIER ::= { protiumTechAlarms 2 }
    alarmStatus             OBJECT IDENTIFIER ::= { protiumTechAlarms 3 }
    alarmStats              OBJECT IDENTIFIER ::= { protiumTechAlarms 4 }
protiumTechRadio           OBJECT IDENTIFIER ::= { protiumTechModel4050 3 }
    radioInfo               OBJECT IDENTIFIER ::= { protiumTechRadio 1 }
    radioConfig             OBJECT IDENTIFIER ::= { protiumTechRadio 2 }
    radioStatus             OBJECT IDENTIFIER ::= { protiumTechRadio 3 }
    radioStats              OBJECT IDENTIFIER ::= { protiumTechRadio 4 }
    radioCalibration        OBJECT IDENTIFIER ::= { protiumTechRadio 5 }
protiumTechModem           OBJECT IDENTIFIER ::= { protiumTechModel4050 4 }
    modemInfo               OBJECT IDENTIFIER ::= { protiumTechModem 1 }
    modemConfig             OBJECT IDENTIFIER ::= { protiumTechModem 2 }
    modemStatus             OBJECT IDENTIFIER ::= { protiumTechModem 3 }
    modemStats              OBJECT IDENTIFIER ::= { protiumTechModem 4 }
protiumTechInterfaces      OBJECT IDENTIFIER ::= { protiumTechModel4050 5 }
    interfacesInfo          OBJECT IDENTIFIER ::= { protiumTechInterfaces 1 }
    interfacesConfig        OBJECT IDENTIFIER ::= { protiumTechInterfaces 2 }
    interfacesStatus        OBJECT IDENTIFIER ::= { protiumTechInterfaces 3 }
    interfacesStats         OBJECT IDENTIFIER ::= { protiumTechInterfaces 4 }
protiumTechManagement      OBJECT IDENTIFIER ::= { protiumTechModel4050 6 }
protiumTechPersistantConfig OBJECT IDENTIFIER ::= { protiumTechModel4050 7 }
protiumTechTestModes       OBJECT IDENTIFIER ::= { protiumTechModel4050 8 }

```

```
--
-- system objects
--

productIdentity OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..64))
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Identification of the Protium Technologies product."
    ::= { systemInfo 1 }

productModelNumber OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..12))
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Model number of the Protium Technologies product."
    ::= { systemInfo 2 }

productDescription OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..64))
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Description of the Protium Technologies product."
    ::= { systemInfo 3 }

productManufacturer OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..64))
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Manufacturer of the Protium Technologies product."
    ::= { systemInfo 4 }

serialNumber OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..12))
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Serial number of this particular system."
    ::= { systemInfo 5 }

embeddedSoftwareVersion OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..24))
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Version number of the embedded software. The format is flexible but
        is generally of the form <major>.<minor>.<revision> where major, minor,
        and revision are numeric fields. The major version identifies significant
        changes if capabiltiy or functionality. The minor version indicates
        a less significant change in functionality. The revision generally
        indicates a fix or improvement to existing functionality."
    ::= { systemInfo 6 }

modemSoftwareVersion OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..24))
```

```

MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "Version number of the embedded software. The format is flexible but
    is generally of the form <major>.<minor>.<revision> where major, minor,
    and revision are numeric fields. The major version identifies significant
    changes if capability or functionality. The minor version indicates
    a less significant change in functionality. The revision generally
    indicates a fix or improvement to existing functionality."
 ::= { systemInfo 7 }

```

radioSoftwareVersion OBJECT-TYPE

```

SYNTAX        OCTET STRING (SIZE(0..24))
MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "Version number of the embedded software. The format is flexible but
    is generally of the form <major>.<minor>.<revision> where major, minor,
    and revision are numeric fields. The major version identifies significant
    changes if capability or functionality. The minor version indicates
    a less significant change in functionality. The revision generally
    indicates a fix or improvement to existing functionality."
 ::= { systemInfo 8 }

```

panelLEDs OBJECT-TYPE

```

SYNTAX        BITS { sysLED(0), dataLED(1), txLED(2), rxLED(3) }
MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "Status of the front and rear panel LED indicators. The system LED
    is normally on; the other LEDs are normally off."
 ::= { systemStatus 1 }

```

relayContacts OBJECT-TYPE

```

SYNTAX        BITS { sysRelay(0), dataRelay(1), txRelay(2), rxRelay(3) }
MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "Status of the relay contacts. The system contact is
    normally closed (1); the other contacts are normally open."
 ::= { systemStatus 2 }

```

coolingFans OBJECT-TYPE

```

SYNTAX        BITS { fan1(0), fan2(1) }
MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "Status of the cooling fans. The numbers of fans in operation
    is temperature dependent."
 ::= { systemStatus 3 }

```

currentAlarms OBJECT-TYPE

```

SYNTAX        BITS { summary(0), modemTemp(1), rfTemp(2), paTemp(3),
                    linkDown(4),
                    txSynthOOL(5), txMuted(6), txNoPower(7), txLowPower(8),
                    rxSynthOOL(9), rxAgcOOL(10), rxLowRsl(11) }
MAX-ACCESS    read-only
STATUS        current
DESCRIPTION
    "A collection of status bits indicating alarm conditions. The alarms are:
    summary      inclusive OR of all the other alarms

```

```

        modemTemp      the modem temperature exceeds the alarm threshold
        rfTemp         the RF module temperature exceeds the alarm threshold
        paTemp         the PA module temperature exceeds the alarm threshold
        linkdown       there is no frame lock on the receiver
        txSynthOOL     the TX frequency synthesizer is out of lock
        txMuted        the transmitter is muted
        txNoPower      no power is detected at the transmitter
        txLowPower     the transmitter power out is abnormally low
        rxSynthOOL     the RX frequency synthesizer is out of lock
        rxAgcOOL       the receiver automatic gain control has excessive error
        rxLowRsl       the receiver signal level is below the alarm threshold"
    ::= { alarmStatus 1 }

--
-- radio objects
--
radioMuteSetting OBJECT-TYPE
    SYNTAX      INTEGER { mute(0), unmute(1) }
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Desired unmute setting."
    ::= { radioConfig 1 }

radioDashVariation OBJECT-TYPE
    SYNTAX      INTEGER { undefined(0), txlow(1), txhigh(2) }
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Value of 1 indicates radio transmits in the low subband and
        receives in the high subband. A value of 2 indicates the radio
        transmits in the high subband and receives in the low subband.
        A value of zero indicates the radio has not been configured. An
        unconfigured radio will not transmit at all."
    ::= { radioConfig 2 }

radioTxFrequencySetting OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "KHz"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Transmit frequency in KHz."
    ::= { radioConfig 3 }

radioRxFrequencySetting OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "KHz"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Receiver frequency in KHz."
    ::= { radioConfig 4 }

radioTxPowerSetting OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "cBm"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Transmit output power in cBm (centibels referred to 1 mW)."
```

```
::= { radioConfig 5 }

radioRslAlarmThreshold OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "cBm"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Low received signal alarm threshold in cBm (centibels referred to 1 mW)."
```

```
::= { radioConfig 6 }

radioTempAlarmThreshold OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "degrees C"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "High temperature alarm threshold of the radio module in degrees C."
```

```
::= { radioConfig 7 }

powerAmpTempAlarmThreshold OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "degrees C"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "High temperature alarm threshold of the power amplifier in degrees C."
```

```
::= { radioConfig 8 }

muteState OBJECT-TYPE
    SYNTAX      INTEGER { unmuted(0), mutedByOper(1), mutedByConfigErr(2),
                        mutedBySynthUnlocked(3), mutedForReconfig(4),
                        mutedByRTS(5) }
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Actual mute state. The value is 1 if the radio is muted by operator
        command; the value is 2 if the operator has attempted to unmute the
        radio but it is prevented by mis-configuration (probably illegal TX
        frequency); the value is 3 if the frequency is okay but the synthesizer
        is out of lock; the value is 4 if the radio is temporarily muted while
        it is being reconfigured; the value is 5 if configured for multi-point
        and the request-to-send (RTS) line on the serial port is negated."
```

```
::= { radioStatus 1 }

txSynthLocked OBJECT-TYPE
    SYNTAX      INTEGER { unlocked(0), locked(1) }
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Transmit synthesizer lock state"
```

```
::= { radioStatus 2 }

rxSynthLocked OBJECT-TYPE
    SYNTAX      INTEGER { unlocked(0), locked(1) }
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Receive synthesizer lock state"
```

```
::= { radioStatus 3 }
```

```
receivedSignalLevel OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "cBm"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Receive signal level in centibels referred to 1 mW."
    ::= { radioStatus 4 }

txAttenuationSetting OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Transmitter attenuation setting."
    ::= { radioStatus 5 }

txDeviationSetting OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Transmitter deviation setting."
    ::= { radioStatus 6 }

radioTemperature OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "degrees C"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Temperature of the radio module in degrees C."
    ::= { radioStatus 7 }

powerAmpTemperature OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "degrees C"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Temperature of the power amplifier in degrees C."
    ::= { radioStatus 8 }

peakRadioTemperaure OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "degrees C"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Peak temperature of the radio module in degrees C."
    ::= { radioStats 7 }

peakPowerAmpTemperature OBJECT-TYPE
    SYNTAX      Integer32
    UNITS       "degrees C"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Peak temperature of the power amplifier in degrees C."
    ::= { radioStats 8 }
```

```

deviation64K    OBJECT-TYPE
    SYNTAX      Unsigned32(0..1023)
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Deviation calibration setting for 64K link speed."
    ::= { radioCalibration 1 }

deviation128K   OBJECT-TYPE
    SYNTAX      Unsigned32(0..1023)
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Deviation calibration setting for 128K link speed."
    ::= { radioCalibration 2 }

tcxoCalSetting  OBJECT-TYPE
    SYNTAX      Unsigned32(0..1023)
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "TCXO calibration setting."
    ::= { radioCalibration 3 }

txAttenOffset   OBJECT-TYPE
    SYNTAX      Integer32(-32..31)
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Transmit power calibration setting."
    ::= { radioCalibration 4 }

rslCalOffset    OBJECT-TYPE
    SYNTAX      Integer32(-32..31)
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Inferred receive signal level calibration setting."
    ::= { radioCalibration 5 }

--
-- protiumTechModem objects
--

interleave      OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Interleave factor: 0 through 6. Both 0 and 1 are no interleave"
    ::= { modemConfig 1 }

clearRsStats    OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Clears Reed-Soloman statistics counters when read. Always reads 0."
    ::= { modemConfig 2 }

modemTempAlarmThreshold OBJECT-TYPE

```



```
SYNTAX      Integer32
UNITS       "degrees C"
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "High temperature alarm threshold of the modem module in degrees C."
 ::= { modemConfig 3 }

frameLocked OBJECT-TYPE
SYNTAX      INTEGER { unlocked(0), locked(1) }
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "Receive frame lock state"
 ::= { modemStatus 1 }

modemTemperature OBJECT-TYPE
SYNTAX      Integer32
UNITS       "degrees C"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "Temperature of the modem board in degrees C."
 ::= { modemStatus 3 }

peakModemTemperature OBJECT-TYPE
SYNTAX      Integer32
UNITS       "degrees C"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "Peak temperature of the modem board in degrees C."
 ::= { modemStatus 4 }

totalKBytes OBJECT-TYPE
SYNTAX      Counter32
UNITS       "KBytes"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "Number of kilobytes processed by the R-S decoder
    (using the computer science definition of 1024 bytes
    per kilobyte)."
 ::= { modemStats 1 }

correctedBytes OBJECT-TYPE
SYNTAX      Counter32
UNITS       "bytes"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "Number of bytes corrected by the R-S decoder."
 ::= { modemStats 2 }

totalBlocks OBJECT-TYPE
SYNTAX      Counter32
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "Number of blocks processed by the R-S decoder."
 ::= { modemStats 3 }
```

```
erroredBlocks OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that had errors."
    ::= { modemStats 4 }

uncorrectedBlocks OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that had uncorrectable errors."
    ::= { modemStats 5 }

correctedBlocks OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that had corrected errors."
    ::= { modemStats 6 }

errorHistogram OBJECT IDENTIFIER ::= { modemStats 7 }

blocksWith1Errs OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that
        had 1 corrected error byte."
    ::= { errorHistogram 1 }

blocksWith2Errs OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that
        had 2 corrected error bytes."
    ::= { errorHistogram 2 }

blocksWith3Errs OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that
        had 3 corrected error bytes."
    ::= { errorHistogram 3 }

blocksWith4Errs OBJECT-TYPE
    SYNTAX Counter32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that
        had 4 corrected error bytes."
```

```
::= { errorHistogram 4 }

blocksWith5Errs OBJECT-TYPE
    SYNTAX      Counter32
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that
        had 5 corrected error bytes."
    ::= { errorHistogram 5 }

blocksWith6Errs OBJECT-TYPE
    SYNTAX      Counter32
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "Number of blocks processed by the R-S decoder that
        had 6 corrected error bytes."
    ::= { errorHistogram 6 }

--
-- interfacesInfo objects
--

dataSharerExists    OBJECT-TYPE
    SYNTAX      INTEGER { no(0), yes(1) }
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "Whether a data sharer (port B) exists."
    ::= { interfacesInfo 1 }

--
-- interfacesConfig objects
--

baudrate    OBJECT-TYPE
    SYNTAX      Unsigned32
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Asynchronous: 300 | 600 | 1200 | 2400 | 4800 | 9600 | 14400 | 19200
        Synchronous: 64 | 128"
    ::= { interfacesConfig 1 }

serialMode    OBJECT-TYPE
    SYNTAX      INTEGER { synchronous(0), asynchronous(1) }
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "Serial port protocol. This is read-only because it is set
        implicitly by the baudrate"
    ::= { interfacesConfig 2 }

interfaceType    OBJECT-TYPE
    SYNTAX      INTEGER { eia530(0), eia232(1) }
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Interface driver type"
```

```

::= { interfacesConfig 3 }

clockSource OBJECT-TYPE
    SYNTAX      INTEGER { internal(0), external(1), looped(2) }
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Synchronous serial clock source"
    ::= { interfacesConfig 4 }

sharerOutputGated OBJECT-TYPE
    SYNTAX      INTEGER { notGated(0), gated(1) }
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Data sharer received data output selection. If not gated, received
        data is output on both ports. If gated, received data is only output
        on the currently active port."
    ::= { interfacesConfig 5 }

sharerRtsEnables OBJECT-TYPE
--    SYNTAX      BITS { portA(0), portB(1) }
    SYNTAX      INTEGER { neither(0), portA(1), portB(2), both(3) }
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "Data sharer transmit data input selection. Access is governed by
        the RTS signals. If only one port has RTS asserted, that port will
        be granted access. If both ports have RTS asserted, port A has
        priority and will get access. If neither port has RTS asserted,
        port A will get access by default."
    ::= { interfacesConfig 6 }

--
-- interfacesStatus objects
--
selectedSerialPort OBJECT-TYPE
    SYNTAX      INTEGER { PortA(0), PortB(1) }
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "Which data sharer is currently selected."
    ::= { interfacesStatus 1 }

statusSerialPortA OBJECT-TYPE
    SYNTAX      BITS { RTS(0), CTS(1), DTR(2), DSR(3),
                      RLSD(4), LL(5), RL(6), TM(7) }
    MAX-ACCESS   read-only
    STATUS      current
    DESCRIPTION
        "The current status of the modem control lines:
        RTS      Request To Send
        CTS      Clear To Send
        DTR      Data Terminal Ready
        DSR      Data Set Ready
        RLSD     Receive Line Signal Detected
        LL       Local Loopback
        RL       Remote Loopback
        TM       Test Mode"
    ::= { interfacesStatus 2 }

```

```
statusSerialPortB OBJECT-TYPE
    SYNTAX      BITS {   RTS(0), CTS(1), DTR(2), DSR(3),
                        RLSD(4), LL(5), RL(6), TM(7) }
    MAX-ACCESS   read-only
    STATUS       current
    DESCRIPTION
        "The current status of the modem control lines:
        RTS      Request To Send
        CTS      Clear To Send
        DTR      Data Terminal Ready
        DSR      Data Set Ready
        RLSD     Receive Line Signal Detected
        LL       Local Loopback
        RL       Remote Loopback
        TM       Test Mode"
    ::= { interfacesStatus 3 }

--
-- protiumTechPersistantConfig objects
--

hostname OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..32))
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "hostname of the processor"
    ::= { protiumTechPersistantConfig 1 }

dnsServer1 OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "dotted quad of our primary DNS server"
    ::= { protiumTechPersistantConfig 2 }

dnsServer2 OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "dotted quad of our secondary DNS server"
    ::= { protiumTechPersistantConfig 3 }

defaultGateway OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "dotted quad of our default gateway"
    ::= { protiumTechPersistantConfig 4 }

timeserver OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(0..64))
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "host name (or IP number) of an ntp timeserver"
    ::= { protiumTechPersistantConfig 5 }
```

```
mgmtPortDhcpEnable OBJECT-TYPE
    SYNTAX      INTEGER { disabled(0), enabled(1) }
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "If enabled, use DHCP to configure the management ethernet port"
    ::= { protiumTechPersistantConfig 6 }

mgmtPortIPv4Address OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "dotted quad of management ethernet port if manually configured"
    ::= { protiumTechPersistantConfig 7 }

mgmtPortNetmask OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "dotted quad of netmask for management ethernet port if manually configured"
    ::= { protiumTechPersistantConfig 8 }

mgmtPortHardwareAddress OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(18))
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "Hardware MAC address for management ethernet port"
    ::= { protiumTechPersistantConfig 9 }

dataPortDhcpEnable OBJECT-TYPE
    SYNTAX      INTEGER { disabled(0), enabled(1) }
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "If enabled, use DHCP to configure the management ethernet port"
    ::= { protiumTechPersistantConfig 10 }

dataPortIPv4Address OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "dotted quad of payload ethernet port if manually configured"
    ::= { protiumTechPersistantConfig 11 }

dataPortNetmask OBJECT-TYPE
    SYNTAX      IpAddress
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "dotted quad of netmask for payload ethernet port if manually configured"
    ::= { protiumTechPersistantConfig 12 }

dataPortHardwareAddress OBJECT-TYPE
    SYNTAX      OCTET STRING (SIZE(18))
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
```

```
"Hardware MAC address for payload ethernet port"
::= { protiumTechPersistantConfig 13 }

--
-- testModes objects
--

panelLedTM OBJECT-TYPE
    SYNTAX      INTEGER { normal(0), on(1) }
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Test all panel LEDs. All Leds are forced on."
    ::= { protiumTechTestModes 1 }

alarmRelayTM OBJECT-TYPE
    SYNTAX      INTEGER { normal(0), on(1) }
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Test all alarm relays. Alarm relay states are inverted."
    ::= { protiumTechTestModes 2 }

coolingFansTM OBJECT-TYPE
    SYNTAX      INTEGER { normal(0), on(1) }
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Test both cooling fans. Both fans are forced on."
    ::= { protiumTechTestModes 3 }

loopbackTM OBJECT-TYPE
    SYNTAX      INTEGER { off(0), local(1), remote(2), locrem(3), traffic(4) }
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Local loopback loops the interface receivers to the
        drivers. No modem functions are exercised.
        Remote loopback loops the received bit stream back to
        the transmitter. Symbol decoding and encoding are
        exercised; Interleaving and error correction are not.
        Traffic loopback loops the local interface input to
        the local output. Serialization, deserialization,
        framing, interleaving, and error correction are all
        exercised; symbol encoding and decoding are not."
    ::= { protiumTechTestModes 4 }

rfLoopbackTM OBJECT-TYPE
    SYNTAX      INTEGER { off(0), on(1) }
    MAX-ACCESS   read-write
    STATUS       current
    DESCRIPTION
        "Attempt RF loopback. Sets the receiver to the same
        frequency as the transmitter and set the transmitter
        to minimum power (maximum attenuation). Leakage may
        allow the radio to receive its own signal. Maybe."
    ::= { protiumTechTestModes 5 }

modulationTM OBJECT-TYPE
    SYNTAX      INTEGER { normal(0), off(1) }
    MAX-ACCESS   read-write
```

```
STATUS      current
DESCRIPTION
    "Disable modulation and output a CW carrier."
::= { protiumTechTestModes 6 }

disableAgcTM OBJECT-TYPE
SYNTAX      INTEGER { normal(0), disabled(1) }
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "Disable receiver automatic gain control."
::= { protiumTechTestModes 7 }

disableApcTM OBJECT-TYPE
SYNTAX      INTEGER { normal(0), disabled(1) }
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "Disable the transmitter temperature compensated
    power control."
::= { protiumTechTestModes 8 }

disableRfModuleTM OBJECT-TYPE
SYNTAX      INTEGER { normal(0), disabled(1) }
MAX-ACCESS  read-write
STATUS      current
DESCRIPTION
    "Communication with the RF module is disabled. The SPI bus
    to the PIC processor will not be used. The RF module remains
    in its current state."
::= { protiumTechTestModes 9 }

END
```


Appendix B Software Licenses

B.1 Protium Technologies, Inc. Proprietary Software License

SOFTWARE LICENSE AGREEMENT

PLEASE READ THIS SOFTWARE LICENSE AGREEMENT CAREFULLY BEFORE DOWNLOADING OR USING THE SOFTWARE.

Single User License Grant: Protium Technologies, Inc. ("Protium") and its suppliers grant to Customer ("Customer") a nonexclusive and nontransferable license to use the Protium software ("Software") in object code form solely on a single central processing unit owned or leased by Customer or otherwise embedded in equipment provided by Protium.

Customer may make one (1) archival copy of the Software provided Customer affixes to such copy all copyright, confidentiality, and proprietary notices that appear on the original.

EXCEPT AS EXPRESSLY AUTHORIZED ABOVE, CUSTOMER SHALL NOT: COPY, IN WHOLE OR IN PART, SOFTWARE OR DOCUMENTATION; MODIFY THE SOFTWARE; REVERSE COMPILE OR REVERSE ASSEMBLE ALL OR ANY PORTION OF THE SOFTWARE; OR RENT, LEASE, DISTRIBUTE, SELL, OR CREATE DERIVATIVE WORKS OF THE SOFTWARE. Customer agrees that aspects of the licensed materials, including the specific design and structure of individual programs, constitute trade secrets and/or copyrighted material of Protium. Customer agrees not to disclose, provide, or otherwise make available such trade secrets or copyrighted material in any form to any third party without the prior written consent of Protium. Customer agrees to implement reasonable security measures to protect such trade secrets and copyrighted material. Title to Software and documentation shall remain solely with Protium.

LIMITED WARRANTY. Protium warrants that for a period of sixty (60) days from the date of shipment from Protium: (i) the media on which the Software is furnished will be free of defects in materials and workmanship under normal use; and (ii) the Software substantially conforms to its published specifications. Except for the foregoing, the Software is provided AS IS. This limited warranty extends only to Customer as the original licensee. Customer's exclusive remedy and the entire liability of Protium and its suppliers under this limited warranty will be, at Protium's option, repair, replacement, or refund of the Software if reported (or, upon request, returned) to the party supplying the Software to Customer. In no event does Protium warrant that the Software is error free or that Customer will be able to operate the Software without problems or interruptions.

This warranty does not apply if the software (a) has been altered, except by Protium, (b) has not been installed, operated, repaired, or maintained in accordance with instructions supplied by Protium, (c) has been subjected to abnormal physical or electrical stress, misuse, negligence, or accident, or (d) is used in hazardous activities.

DISCLAIMER. EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE EXTENT ALLOWED BY APPLICABLE LAW. IN NO EVENT WILL PROTIUM OR ITS SUPPLIERS BE LIABLE FOR ANY LOST REVENUE, PROFIT, OR DATA, OR FOR SPECIAL, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWEVER

CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE EVEN IF PROTIUM OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. In no event shall Protium's or its suppliers' liability to Customer, whether in contract, tort (including negligence), or otherwise, exceed the price paid by Customer. The foregoing limitations shall apply even if the above-stated warranty fails of its essential purpose. SOME STATES DO NOT ALLOW LIMITATION OR EXCLUSION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES.

The above warranty DOES NOT apply to any beta software, any software made available for testing or demonstration purposes, any temporary software modules or any software for which Protium does not receive a license fee. All such software products are provided AS IS without any warranty whatsoever.

This License is effective until terminated. Customer may terminate this License at any time by destroying all copies of Software including any documentation. This License will terminate immediately without notice from Protium if Customer fails to comply with any provision of this License. Upon termination, Customer must destroy all copies of Software.

Subject software, including technical data, is subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software.

This License shall be governed by and construed in accordance with the laws of the Commonwealth of Massachusetts, United States of America, as if performed wholly within the state and without giving effect to the principles of conflict of law. If any portion hereof is found to be void or unenforceable, the remaining provisions of this License shall remain in full force and effect. This License constitutes the entire License between the parties with respect to the use of the Software.

Restricted Rights - Protium's software is provided to non-DOD agencies with RESTRICTED RIGHTS and its supporting documentation is provided with LIMITED RIGHTS. Use, duplication, or disclosure by the Government is subject to the restrictions as set forth in subparagraph "C" of the Commercial Computer Software - Restricted Rights clause at FAR 52.227-19. In the event the sale is to a DOD agency, the government's rights in software, supporting documentation, and technical data are governed by the restrictions in the Technical Data Commercial Items clause at DFARS 252.227-7015 and DFARS 227.7202. Manufacturer is Protium Technologies, Inc., 10 Bearfoot Road, Northborough, MA 01532.

B.2 GNU General Public License, Version 2

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE
TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such

interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a

special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

B.3 GNU Library General Public License, Version 2

GNU LIBRARY GENERAL PUBLIC LICENSE Version 2, June 1991

Copyright (C) 1991 Free Software Foundation, Inc.
675 Mass Ave, Cambridge, MA 02139, USA
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

[This is the first released version of the library GPL. It is
numbered 2 because it goes with version 2 of the ordinary GPL.]

Preamble

The licenses for most software are designed to take away your
freedom to share and change it. By contrast, the GNU General Public
Licenses are intended to guarantee your freedom to share and change
free software--to make sure the software is free for all its users.

This license, the Library General Public License, applies to some
specially designated Free Software Foundation software, and to any
other libraries whose authors decide to use it. You can use it for
your libraries, too.

When we speak of free software, we are referring to freedom, not
price. Our General Public Licenses are designed to make sure that you
have the freedom to distribute copies of free software (and charge for
this service if you wish), that you receive source code or can get it
if you want it, that you can change the software or use pieces of it
in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid
anyone to deny you these rights or to ask you to surrender the rights.
These restrictions translate to certain responsibilities for you if
you distribute copies of the library, or if you modify it.

For example, if you distribute copies of the library, whether gratis
or for a fee, you must give the recipients all the rights that we gave
you. You must make sure that they, too, receive or can get the source
code. If you link a program with the library, you must provide
complete object files to the recipients so that they can relink them
with the library, after making changes to the library and recompiling
it. And you must show them these terms so they know their rights.

Our method of protecting your rights has two steps: (1) copyright
the library, and (2) offer you this license which gives you legal
permission to copy, distribute and/or modify the library.

Also, for each distributor's protection, we want to make certain
that everyone understands that there is no warranty for this free
library. If the library is modified by someone else and passed on, we

want its recipients to know that what they have is not the original version, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that companies distributing free software will individually obtain patent licenses, thus in effect transforming the program into proprietary software. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License, which was designed for utility programs. This license, the GNU Library General Public License, applies to certain designated libraries. This license is quite different from the ordinary one; be sure to read it in full, and don't assume that anything in it is the same as in the ordinary license.

The reason we have a separate public license for some libraries is that they blur the distinction we usually make between modifying or adding to a program and simply using it. Linking a program with a library, without changing the library, is in some sense simply using the library, and is analogous to running a utility program or application program. However, in a textual and legal sense, the linked executable is a combined work, a derivative of the original library, and the ordinary General Public License treats it as such.

Because of this blurred distinction, using the ordinary General Public License for libraries did not effectively promote software sharing, because most developers did not use the libraries. We concluded that weaker conditions might promote sharing better.

However, unrestricted linking of non-free programs would deprive the users of those programs of all benefit from the free status of the libraries themselves. This Library General Public License is intended to permit developers of non-free programs to use free libraries, while preserving your freedom as a user of such programs to change the free libraries that are incorporated in them. (We have not seen how to achieve this as regards changes in header files, but we have achieved it as regards changes in the actual functions of the Library.) The hope is that this will lead to faster development of free libraries.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, while the latter only works together with the library.

Note that it is possible for a library to be covered by the ordinary General Public License rather than by this special one.

GNU LIBRARY GENERAL PUBLIC LICENSE
TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Library General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no

charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or

derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also compile or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference

directing the user to the copy of this License. Also, you must do one of these things:

- a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- b) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- c) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- d) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact

that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Library General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH

DAMAGES .

END OF TERMS AND CONDITIONS

Appendix C GLOSSARY

BERT	Bit-Error Rate Test. A test to determine the BER.
BER	Bit-Error Rate. The ratio of the number of incorrect bits received to the total number of bits received. The bit-error rate is usually expressed in scientific notation such as 1.0×10^{-6} or 1.0E-6.
Bit	Binary “digit.” A bi-valued entity representing the smallest unit of information and generally represented by zero (“0”) or one (“1”).
bps	Bits Per Second.
byte	Eight bits.
dB	Decibel. The ratio of two power levels expressed as ten times the base 10 logarithm of the ratio.
dBm	An absolute power measurement expressed as decibels relative to one milliwatt.
CIT	Craft Interface Terminal. A generic text-based terminal with an EIA-232 serial interface used for local management functions. This may be a dedicated text terminal, a personal computer with terminal emulator software, or a Personal Digital Assistant (PDA) with serial port and terminal emulator software.
DCE	Data Communications Equipment. The communication equipment, such as a modem, involved in a communication channel. Contrast with DTE.
DNS	Domain Name Server. A network server that provides a service to map network domain names to IP network addresses.
DHCP	Dynamic Host Configuration Protocol. A network protocol used to automatically (and dynamically) configure an IP network port.
DTE	Date Terminal Equipment. The end node equipment involved in a communication channel. The DTE is the source and/or destination for the information sent over the communication channel. Contrast with DCE.
EIA	Electronic Industries Alliance.
FCC	Federal Communications Commission.
FEC	Forward Error Correction. A means by which errors that corrupt a message sent through a communication channel may be corrected. In FEC, redundant information is added to the message at the sender and processed at the receiver so that the original message may be recovered intact in spite of certain errors.
GHz	Gigahertz. A frequency of 1,000,000,000 cycles per second.
GPL	GNU General Public License. A license agreement for open-source software (copyrighted by the Free Software Foundation).
IP	Internet Protocol.
Kbps	Kilobits per second.
LGPL	GNU Library General Public License. A license agreement for open-source software (copyrighted by the Free Software Foundation). The LGPL is typically used for libraries and other software “building blocks.”

MDIX	Media Dependent Interface - Crossover. An Ethernet port connection using twisted pair cabling where a null-modem (or crossover) function is inherent in the pin assignments in the connector.
MIB	Management Information Base. The database of values, parameters, and events managed by SNMP for an entity (device).
MHz	Megahertz. A frequency of 1,000,000 cycles per second.
NTP	Network Time Protocol. An network protocol that allows real-time clocks to be synchronized via the network. Often used to synchronize local clocks to a standard reference.
RMS	Remote Management System. A generic reference to software used to manage (configure, monitor, and troubleshoot) the equipment remotely via a network connection.
RO	Read Only. A read-only value may be displayed but not changed.
RF	Radio Frequency.
RSL	Received Signal Level. The received signal power usually expressed in dBm.
RW	Read-Write. A read-write value may be displayed and changed.
SNMP	Simple Network Management Protocol. A common protocol for managing devices via a network that is anything but simple.
SNR	Signal-to-Noise Ratio, expressed in dB.
TCP	Transmission Control Protocol. TCP is a layered protocol based on the Internet Protocol as its underlying protocol. TCP is connection and stream oriented. It provides for reliable communication over packet-switched networks by using flow control, packet retransmission, and other techniques.

